



109-1200

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	323 326 40	1	Motor	Engine
02	501 005 98	6	Schraube	Screw
03	288 956 40	2	Lagerbock	Bracket
04	288 955 40	2	Abdeckblech	Cover
05	288 959 40	6	Scheibe	Washer
06	327 442 40	2	Motorlager	Mounting
07	343 112 99	16	Federring	Lock washer
08	325 607 99	8	Schraube	Screw
09	327 469 40	2	Distanzklotz, entfällt ab Bau-Nr.35 026	Spacer block, not used from s/no:35 026
10	327 471 40	2	Lagerbock bis Bau-Nr. 35 006	Bracket up to serial-no: 35 006
11	288 957 40	2	Gummilager	Rubber pad
12	332 334 99	8	Mutter	Nut
13	327 940 40	1	Keilriemen bis Bau-Nr. 35 052	V-belt up to s/no: 35 052
13	030 258 98	1	Keilriemen ab Bau-Nr. 35 053	V-belt from s/no: 35 053
14	307 805 99	8	Schraube	Screw
15	332 334 99	8	Mutter	Nut
16	307 823 99	4	Schraube	Screw
17	343 116 99	4	Federring	Lock washer
18	332 226 99	4	Mutter	Nut
19	343 700 40	2	Lagerbock ab Bau-Nr. 35 007	Bearing support from serial-no: 35 007