



109-6025-2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	348 473 40	1	I. Innenkasten, kpl. (best. aus Bild-Nr. 02-52)	I. Inner case, cpl. (consist. of fig-nos: 02-52)
02	348 472 40	1	I. Innenkasten (Sk) einschl. Bild-Nr. 45-52	I. Inner case incl. fig-nos: 45-52
03	322 017 40	2	Führung oben, kpl. einschl. Bild-Nr. 04-07	Guide, above, assy. incl. fig-nos: 04-07
04	322 022 40	2	Gleitstück (anpassen)	Slider (adapt)
05	320 433 99	6	Schraube	Screw
06	332 111 99	6	Mutter	Nut
07	003 121 98	6	DUBO-Sicherung	Screw lock
08	328 828 40	2	Gleitschuh unten, kpl. einschl. Bild-Nr. 09-12	Guide shoe, below, assy. incl. fig-nos: 09-12
09	328 837 40	2	Gleitstück (anpassen)	Slider (adapt)
10	321 229 99	8	Schraube	Screw
11	003 121 98	8	DUBO-Sicherung	Screw lock
12	332 111 99	8	Mutter	Nut
13	285 288 40	1	Führung links, kpl. einschl. Bild-Nr. 15-18	Guide, l.h., assy. incl. fig-nos: 15-18
14	285 294 40	1	Führung rechts, kpl. einschl. Bild-Nr. 15-18	Guide, r.h., assy. incl. fig-nos: 15-18
15	285 293 40	2	Gleitstück (anpassen)	Slider (adapt)
16	320 421 99	6	Schraube	Screw
17	332 111 99	6	Mutter	Nut
18	003 121 98	6	DUBO-Sicherung	Screw lock
19	328 833 40	1	Rohr	Pipe
20	328 835 40	1	Stange	Rod
21	328 834 40	2	Buchse	Bush
22	328 829 40	2	Bolzen	Pin
23	328 832 40	2	Achshalter	Axle lock
24	308 631 99	8	Schraube	Screw
25	343 116 99	14	Federring	Lock washer
26	322 102 40	14	Scheibe	Washer
27	003 818 98	4	Mutter	Nut
28	307 823 99	6	Schraube	Screw
29	342 063 99	2	Splint	Split pin
30	328 830 40	4	Buchse	Bush
31	328 831 40	2	Blech	Strip
33	311 390 40	2	Knagge	Strip
34	311 367 40	2	Blech	Strip
36	307 750 99	4	Schraube	Screw

**I. Innenkasten
I. Inner Case**

109-6025-2

Seite/Page 2 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
37	346 510 99	4	Federring	Lock washer
45	328 758 40	1	Rohr	Pipe
46	501 584 98	1	Platte	Plate
47	501 559 98	14	Schelle	Clamp
48	340 463 99	14	Scheibe	Washer
49	319 417 99	14	Schraube	Screw
50	373 911 99	1	Rohrschelle	Clamp
51	307 773 99	2	Schraube	Screw
52	346 500 99	2	Federring	Lock washer
53	319 539 40	1	Gleitstück	Slider
54	319 540 40	1	Gleitstück	Slider
55	350 562 99	2	Schmiernippel	Grease nipple

I. Innenkasten
I. Inner Case

109-6025-2

Seite/Page 3 / 3