



<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
00	874 582 40	1	Verteilerkasten Motor, kpl.	Distribution box engine assy.
01	874 583 40	1	Leergehäuse	Housing, empty
02	321 018 99	4	Zylinderschraube	Screw
03	332 110 99	4	Mutter	Nut
04	346 499 99	4	Federring	Lock washer
05	356 256 40	2	Druckhaube, rot	Push hood, red
06	634 144 40	6	Sicherungsklemme	Fuse clamp
07	654 706 40	6	Überstrom-Schutzschalter 6A	Excess-current switch
08	551 695 40	11	Klemme	Clamp
09	551 698 40	2	Bezeichnungskarte 1-100	Marker 1-100
10	604 141 40	2	Schlauchverschraubung	Union
11	600 808 99	2	Mutter	Nut
12	592 987 40	2	Schutzschlauch	Protecting hose

**Verteilerkasten Motor**  
**Distribution Box Engine**

**117-7346**

Seite/Page 2 / 2