



117-7382

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	874 585 40	1	Verteilerkasten, kpl.	Distribution box assy.
01	874 583 40	1	Leergehäuse	Housing, empty
02	321 018 99	4	Zylinderschraube	Screw
03	332 110 99	4	Mutter	Nut
04	346 499 99	4	Federring	Lock washer
05	356 256 40	2	Druckhaube, rot	Push hood, red
06	551 695 40	11	Klemme	Clamp
07	551 698 40	2	Bezeichnungskarte	Marker
08	604 141 40	2	Schlauchverschraubung	Union
09	600 808 99	2	Mutter	Nut
10	592 987 40	2	Schutzschlauch	Protecting hose

**Verteilerkasten
Distribution Box**

117-7382

Seite/Page 2 / 2