



123-1920

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripción Designazione Benaemning
01	-	1	Lagerbock siehe EL-Blatt 123-1925	Bearing support see page 123-1925
02	335 083 40	1	Hebel	Lever
03	260 032 40	1	Halter bis Bau-Nr. 38 027	Retainer up to s/no: 38 027
03	408 049 40	1	Halter ab Bau-Nr. 38 028	Retainer from s/no: 38 028
04	336 198 40	1	Welle	Shaft
05	360 611 40	1	Fußhebel	Pedal
06	254 740 40	1	Stange	Rod
07	367 048 40	1	Halter	Retainer
08	269 265 40	1	Betätigungszug, L = 5900	Control cable
09	288 909 40	1	Handgaszug L = 1005	Speed handle connection
10	254 930 40	1	Stopzug, L = 5500 bis Bau-Nr.38 002	Stop cable up to serial-no: 38 002
11	640 630 40	1	Zugfeder	Draw spring
12	256 902 40	1	Pedalgummi	Pedal rubber
13	049 513 40	4	Buchse	Bush
14	-	1	Welle siehe EL-Blatt 123-1925	Shaft see page 123-1925
16	350 750 99	2	Gabelkopf	Clevis
17	350 749 99	3	Gabelkopf	Clevis
18	002 825 98	2	ES-Bolzen	Clip
19	002 824 98	3	ES-Bolzen	Clip
21	307 754 99	2	Schraube	Screw
22	318 577 99	2	Schraube	Screw
23	346 509 99	2	Federring	Lock washer
24	320 821 99	4	Schraube	Screw
25	332 111 99	4	Mutter	Nut
26	332 110 99	6	Mutter	Nut
27	346 510 99	2	Federring	Lock washer
28	343 176 99	6	Federscheibe	Lock washer
29	332 109 99	2	Mutter	Nut
30	307 295 99	2	Schraube	Screw
31	367 049 40	1	Hebel	Lever
33	307 727 99	2	Schraube	Screw
34	196 437 40	1	Zugfeder	Spring
35	348 886 40	1	Stopzug ab Bau-Nr. 38 003	Stop cable from serial-no: 38 003
40	393 922 40	1	Distanzrohr ab Bau-Nr. 38 028	Distance sleeve from s/no: 38 028
41	393 921 40	1	Distanzrohr ab Bau-Nr. 38 028	Distance sleeve from s/no: 38 028

Drehzahlverstellung, Oberwagen
Speed control, superstructure

123-1920

Seite/Page 2 / 2