



Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descrpcion Designazione Benaemning
00	434 497 40	1	III. Innenkasten kpl.	III. Inner case assy.
01	997 885 73	1	III. Innenkasten SK	III. Inner case
02	423 492 40	2	Gleitschuh III/IV IK kpl. (anpassen) best. aus Bild-Nr. 03-07	Guide shoe III/IV inner case assy. (to be adapted) consist. of fig-nos: 03-07
04	434 155 40	2	Gleitstück	Slider
05	321 231 99	8	Schraube	Bolt
06	003 121 98	8	Schraubensicherung	Screw retention
07	332 111 99	8	Mutter	Nut
08	423 891 40	2	Achse	Axle
09	423 889 40	4	Buchse	Bush
10	423 887 40	2	Distanzblech	Spacer
11	423 888 40	2	Achshalter	Axle stirrup
12	311 367 40	2	Distanzblech	Spacer
13	423 883 40	2	Gleitstück unten	Slider, lower
14	423 884 40	2	Deckblech	Cover plate
15	423 885 40	2	Gleitstück oben	Slider, top
16	423 886 40	2	Deckblech	Cover plate
17	394 354 40	1	Rohr	Pipe
18	408 644 40	2	Bolzen	Pin
19	504 770 98	2	Kugellager	Ball bearing
20	342 107 99	2	Splint	Cotter pin
21	307 806 99	4	Schraube	Bolt
22	343 112 99	4	Federring	Lock washer
23	307 750 99	4	Schraube	Bolt
24	346 510 99	4	Federring	Lock washer
25	502 006 98	6	Schraube	Bolt
26	308 459 99	4	Schraube	Bolt
27	332 334 99	4	Mutter	Nut
28	350 478 99	4	Scheibe	Washer
40	434 499 40	1	Anschlagblech	Plate
41	320 326 99	2	Schraube bis Bau-Nr. 38 035	Screw up to s/no: 38 035
41	307 800 99	2	Schraube ab Bau-Nr. 38 036	Bolt from s/no: 38 036
42	343 108 99	2	Federring bis Bau-Nr. 38 035	Lock washer up to s/no: 38 035
42	343 112 99	2	Federring ab Bau-Nr. 38 036	Lock washer from s/no: 38 036
43	435 491 40	1	Gleitbacke links	Lining, l.h.
44	435 490 40	1	Gleitbacke rechts	Lining, r.h.
45	350 562 99	2	Schmiernippel	Grease nipple
46	345 044 99	2	Spannstift	Dowel pin

**III. Innenkasten kpl.
III. Inner Case Assy.**

123-6032-1

Seite/Page 2 / 2