



123-6166

Seite/Page 1 / 2

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaemning |
|---|---|---|---|--|
| 01 | 336 066 40 | 1 | Lasche | Shackle |
| 02 | 386 843 40 | 1 | Lagerung | Support |
| 03 | 206 639 40 | 1 | Seilrolle einschl. Bild-Nr. 04 u. 05 | Sheave incl. fig-nos: 04 and 05 |
| 04 | 002 017 98 | 1 | Lager | Bearing |
| 05 | 500 608 98 | 2 | Sprengring | Snap ring |
| 06 | 336 077 40 | 1 | Bolzen | Pin |
| 07 | 336 078 40 | 1 | Bolzen | Pin |
| 08 | 336 079 40 | 2 | Achshalter | Axle stirrup |
| 09 | 336 080 40 | 2 | Rohr | Pipe |
| 10 | 307 779 99 | 4 | Schraube | Bolt |
| 11 | 500 801 98 | 4 | Sicherungsscheibe | Lock washer |
| 12 | 500 805 98 | 2 | Schraube | Bolt |
| 13 | 500 802 98 | 2 | Sicherungsscheibe | Lock washer |
| 14 | 335 020 99 | 1 | Bolzen | Pin |
| 15 | 342 121 99 | 1 | Splint | Cotter pin |

**Zusatzrolle zur Auslegerspitze
Auxiliary Sheave for Boom Top Section**

123-6166

Seite/Page 2 / 2