



123-6220

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	-	1	Klemmenkasten siehe EL-Blatt 123-6222	Junction box see page 123-6222
02	604 415 40	2	Initiator	Proximity switch
05	453 995 40	1	Initiatorbetätigung	Proximity switch actuation
06	504 043 98	2	Schraube	Bolt
07	343 094 99	2	Federring	Lock washer