



124-6020c1

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	601 194 40	1	Grundkasten, kpl. best. aus Bild-Nr. 01-38	Basic case, assy. consist. of fig-nos: 01-38
01	601 195 40	1	Grundkasten (SK)	Basic case
02	469 225 40	2	Gleitschuh, unten, kpl. einschl. Bild-Nr. 03-06 (anpassen)	Guide shoe, below, assy. incl. fig-nos: 03-06 (to be adapted)
03	469 486 40	2	Gleitstück (anpassen)	Slider (to be adapted)
04	321 231 99	8	Schraube	Screw
05	003 121 98	8	Schraubensicherung	Bolt lock
06	332 111 99	8	Mutter	Nut
07	468 975 40	2	Achse	Axle
08	512 065 40	2	Distanzblech	Distance plate
09	512 066 40	2	Achshalter	Axle stirrup
10	468 974 40	4	Buchse	Bushing
11	307 750 99	4	Schraube	Bolt
12	346 510 99	4	Federring	Lock washer
13	469 223 40	1	Rohr	Pipe
14	510 421 98	6	Pendelkugellager	Self-aligning bearing
15	408 644 40	6	Bolzen	Pin
16	342 107 99	6	Splint	Cotter pin
17	468 873 40	2	Gleitstück (anpassen)	Slider (to be adapted)
18	468 874 40	2	Platte	Plate
19	501 276 98	4	Schraube	Bolt
20	332 226 99	4	Mutter	Nut
21	347 684 99	4	Scheibe	Washer
22	469 224 40	2	Rohr	Pipe
23	308 425 99	4	Schraube	Bolt
24	340 469 99	4	Scheibe	Washer
25	469 221 40	1	Buchse	Bushing
26	469 222 40	1	Buchse	Bushing
27	332 336 99	4	Mutter	Nut
30	435 893 40	1	Blech	Plate
31	307 631 99	4	Schraube	Bolt
32	350 562 99	2	Schmiernippel	Grease nipple
33	511 868 40	1	Stange	Rod
34	511 819 40	1	Stange	Rod
35	340 470 99	4	Scheibe	Disc
36	342 062 99	4	Splint	Cotter pin
40	495 745 40	1	Rohr ø 25	Pipe
41	500 980 98	10	Schellenhälfte	Half clamp
42	340 405 99	10	Scheibe	Washer
43	319 133 99	10	Schraube	Screw

**Grundkasten  
Basic Case**

**124-6020c1**

Seite/Page 2/2