



124-6020c2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	511 400 40	1	Grundkasten	Basic case
01	511 490 40	1	Grundkasten SK	Basic case
02	469 225 40	2	Gleitschuh unten kpl.	Guide shoe lower assy.
03	468 975 40	2	Achse	Axle
04	468 976 40	2	Distanzblech	Spacer
05	468 977 40	2	Achshalter	Axle stirrup
06	468 974 40	4	Buchse	Bushing
07	307 750 99	4	Schraube	Bolt
08	346 510 99	4	Federring	Lock washer
09	311 390 40	2	Knagge (anschweißen)	Driver (to be welded)
10	311 367 40	2	Flacheisen (anschweißen)	Flat iron (to be welded)
11	311 392 40	2	Knagge (anschweißen)	Flat iron (to be welded)
12	469 224 40	2	Rohr	Pipe
13	504 770 98	4	Pendelkugellager	Self-aligning bearing
14	408 644 40	4	Bolzen	Pin
15	342 107 99	4	Splint	Cotter pin
16	423 903 40	6	Knagge (anschweißen)	Driver (to be welded)
17	468 873 40	2	Gleitstück	Slider
18	468 874 40	2	Platte	Plate
19	501 276 98	4	Schraube	Bolt
20	332 226 99	4	Mutter	Nut
21	340 468 99	4	Scheibe	Disc
22	502 390 98	4	Schraube	Bolt
23	340 469 99	4	Scheibe	Disc
24	332 336 99	4	Mutter	Nut
25	469 221 40	1	Buchse	Bushing
26	469 222 40	1	Buchse	Bushing
27	435 893 40	1	Blech	Plate
28	307 631 99	4	Schraube	Bolt
29	502 868 99	4	Platte	Plate
30	350 562 99	2	Schmiernippel	Grease nipple
31	511 819 40	1	Rundstahl	Round bar steel
32	340 470 99	2	Scheibe	Disc
33	342 062 99	2	Splint	Cotter pin
43	469 486 40	2	Gleitstück (anpassen)	Slider (to be adapted)
44	321 231 99	8	Schraube	Screw
45	003 121 98	8	Schraubensicherung	Bolt lock
46	332 111 99	8	Mutter	Nut

**Grundkasten**  
**Basic Case**

**124-6020c2**

Seite/Page 2/2