



124-6032d

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaemning |
|------------------------------------------------|--------------------------------------------------------------------------------|------------------------------------------------|----------------------------------------------------------------|---------------------------------------------------------------------------------------|
| 00 | 602 933 40 | 1 | III. Innenkasten, kpl. Japanausführung ab Bau-Nr.37 195: | III. Inner case assy. Japan-design from S/No.37 195: |
| 00 | 400 303 12 | 1 | III. Innenkasten, kpl. | III. Inner case assy. |
| 01 | 602 931 40 | 1 | III. Innenkasten (SK) | III. Inner case |
| 02 | 468 365 40 | 2 | Gleitschuh, unten kpl. einschl. Bild-Nr. 03-06 | Guide shoe, below assy. incl. fig-nos: 03-06 |
| 03 | 602 900 40 | 2 | Gleitstück (anpassen) | Slider (to be adapted) |
| 04 | 321 231 99 | 8 | Schraube | Bolt |
| 05 | 003 121 98 | 8 | Schraubensicherung | Bolt lock |
| 06 | 332 111 99 | 4 | Mutter | Nut |
| 07 | 468 959 40 | 2 | Achse | Axle |
| 08 | 511 159 40 | 4 | Buchse | Bushing |
| 09 | 311 367 40 | 2 | Halter | Retainer |
| 10 | 468 958 40 | 2 | Distanzblech | Spacer |
| 11 | 468 957 40 | 2 | Achshalter | Axle retainer |
| 12 | 508 814 98 | 4 | Schraube | Bolt |
| 13 | 332 334 99 | 4 | Mutter | Nut |
| 14 | 504 271 98 | 4 | Federring | Lock washer |
| 15 | 307 750 99 | 4 | Schraube | Bolt |
| 16 | 468 949 40 | 2 | Gleitstück (anpassen) | Slider (to be adapted) |
| 17 | 468 948 40 | 2 | Halter | Retainer |
| 18 | 500 195 98 | 4 | Schraube | Bolt |
| 19 | 332 226 99 | 4 | Mutter | Nut |
| 19 | 507 221 98 | 4 | Sicherungsmutter ab Bau-Nr. 37 224 | Lock nut from s/no: 37 224 |
| 20 | 347 684 40 | 4 | Scheibe | Washer |
| 20 | 512 151 98 | 4 | Scheibe ab Bau-Nr. 37 224 | Washer from s/no: 37 224 |
| 21 | 468 954 40 | 1 | Rohrstück | Pipe |
| 22 | 504 770 98 | 2 | Pendelrollenlager | Self-aligning bearing |
| 23 | 408 644 40 | 2 | Bolzen | Pin |
| 24 | 342 107 99 | 2 | Splint | Cotter pin |
| 25 | 469 313 40 | 2 | Gleitstück (anpassen) | Slider (to be adapted) |
| 26 | 469 314 40 | 2 | Distanzblech | Spacer |
| 27 | 502 210 98 | 6 | Schraube | Bolt |
| 28 | 319 140 99 | 1 | Schraube | Bolt |
| 29 | 468 353 40 | 1 | Gleitschuh, links | Guide shoe, l.h. |
| 30 | 468 352 40 | 1 | Gleitschuh, rechts | Guide shoe, r.h. |
| 31 | 350 562 99 | 2 | Schmiernippel | Grease nipple |

**III. Innenkasten
III. Inner Case**

124-6032d

Seite/Page 2 / 3

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaeming |
|-------------------------------------------------------|---------------------------------------------------------------------------------------|-------------------------------------------------------|-----------------|---------------------------------------------------------------------------------------------|
| 32 | 343 854 99 | 1 | Federring | Lock washer |
| 33 | 342 082 99 | 1 | Splint | Cotter pin |
| 34 | 001 644 98 | 1 | Sicherungsfeder | Locking spring |
| 40 | 484 401 40 | 1 | Haltebügel | Retainer |
| 48 | 496 894 40 | 1 | Rohr | Barrel |
| 49 | 496 892 40 | 1 | Rohr | Barrel |
| 50 | 495 441 40 | 4 | Buchse | Bushing |
| 51 | 496 893 40 | 1 | Stange | Rod |

III. Innenkasten
III. Inner Case

124-6032d

Seite/Page 3 / 3