



130-6035a2

Seite/Page 1 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	446 096 40	1	2. Innenkasten, kpl.	2nd. inner case, assy.
01	446 097 40	1	2. Innenkasten (SK)	2nd. inner case
04	252 285 40	5	Seilrolle einschl. Bild-Nr. 39 + 40	Sheave incl. fig-nos: 39 + 40
05	252 287 40	1	Seilrolle einschl. Bild-Nr. 41 + 42	Sheave incl. fig-nos: 41 + 42
06	252 289 40	1	Festpunkt einschl. Bild-Nr. 07 + 08	Fixed point incl. fig-nos: 07 + 08
07	252 291 40	1	Buchse	Bush
08	350 560 99	1	Schmiernippel	Grease nipple
09	268 898 40	1	Schaltgewicht	Weight
10	-	1	Abschaltung siehe EL-Blatt 132-6285	Switch-off see page 132-6285
11	001 803 98	1	Seilklemme	Rope clamp
12	367 181 40	1	Achse	Axle
13	252 294 40	1	Achse	Axle
14	252 295 40	2	Ring	Ring
15	160 541 40	2	Wellenendscheibe	Shaft end disk
16	407 902 40	2	Buchse	Bush
17	170 345 40	2	Endscheibe	End disk
18	252 296 40	1	Distanzrohr	Distance tube
19	252 297 40	1	Distanzrohr	Distance tube
22	002 813 98	1	Steckstift	Guide pin
23	307 802 99	4	Schraube	Bolt
24	343 112 99	4	Federring	Lock washer
30	342 248 40	1	Bolzen	Pin
31	307 780 99	8	Schraube	Bolt
32	346 500 99	8	Federring	Lock washer
33	582 450 99	1	Drahtseil L=1500	Cable
34	324 167 99	2	Gewindestift	Thread pin
35	345 010 99	1	Spannhülse	Dowel sleeve
39	002 018 98	5	Lager	Bearing
40	500 609 98	10	Sicherungsring	Circlip
41	002 017 98	1	Lager	Bearing
42	500 608 98	2	Sicherungsring	Circlip
50	252 178 40	1	Untere Führung, links, kpl. einschl. Bild-Nr. 51-54 (anpassen)	Lower guide, l.h., assy. incl. fig-nos: 51-54 (to be adjusted)
51	252 177 40	1	Gleitstück (anpassen)	Slide piece (to be adjusted)
52	332 111 99	3	Mutter	Nut

II. Innenkasten
II. Inner Case

130-6035a2

Seite/Page 2 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
53	320 433 99	3	Schraube	Screw
54	003 121 98	3	DUBO-Sicherung	DUBO-safety device
55	252 180 40	1	Untere Führung, rechts, kpl. einschl. Bild-Nr. 56-59 (anpassen)	Lower guide, r.h., assy. incl. fig-nos: 56-59 (to be adjusted)
56	252 179 40	1	Gleitstück (anpassen)	Slide piece (to be adjusted)
57	332 111 99	3	Mutter	Nut
58	320 433 99	3	Schraube	Screw
59	003 121 98	3	DUBO-Sicherung	DUBO-safety device
60	210 608 40	2	Achshalter	Axle support
61	222 128 40	1	Führung	Guide
62	307 804 99	4	Schraube	Bolt
63	318 603 99	2	Schraube	Screw
64	343 853 99	2	Federring	Lock washer
65	350 562 99	2	Schmiernippel	Grease nipple

II. Innenkasten
II. Inner Case

130-6035a2

Seite/Page 3 / 3