

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaemning |
|---|---|---|-----------------------------|--|
| 00 | 644 595 40 | 1 | Verteilerkasten Motor, kpl. | Distribution box motor assy. |
| 01 | 632 566 40 | 1 | Leergehäuse | Housing, empty |
| 02 | 321 018 99 | 4 | Zylinderschraube | Screw |
| 03 | 332 110 99 | 4 | Mutter | Nut |
| 04 | 346 499 99 | 4 | Federring | Lock washer |
| 05 | 323 766 40 | 1 | Flachautomat 50 A | Trip fuse |
| 06 | 323 767 40 | 1 | Flachautomat 25 A | Trip fuse |
| 07 | 634 966 40 | 1 | Drehzahlregler | Speed control |
| 08 | 356 274 40 | 1 | Reihen клемме | Series terminal |
| 09 | 551 695 40 | 5 | Klemme | Clip |
| 10 | 551 698 40 | 2 | Bezeichnungskarte 1-100 | Marker |
| 11 | 604 461 40 | 1 | Anbaugeschäuse | Mounting box |
| 12 | 358 263 40 | 1 | Schutzdeckel | Protection cover |
| 13 | 385 227 40 | 1 | Steckereinsatz 1-16 | Insert |
| 14 | 385 228 40 | 1 | Steckereinsatz 17-32 | Insert |
| 15 | 324 954 40 | 2 | Codierbolzen | Encoder |
| 16 | 320 975 99 | 4 | Zylinderschraube | Screw |
| 17 | 320 976 99 | 4 | Zylinderschraube | Screw |
| 18 | 332 443 99 | 4 | Mutter | Nut |
| 19 | 346 508 99 | 8 | Federring | Lock washer |
| 20 | 324 837 40 | 2 | Schutzschlauch | Protecting hose |
| 21 | 323 982 40 | 2 | Schlauchverschraubung | Hose union |
| 22 | 323 983 40 | 2 | Innentülle | Socket |
| 23 | 336 717 40 | 2 | Endtülle | Socket |
| 24 | 180 221 40 | 1 | Schaltrelais | Switching relay |
| 25 | 350 295 99 | 5 | Blechschräube | Tapping screw |

Verteilerkasten Motor
Distribution Box Motor

157-2115

Seite/Page 2 / 2