



**168-2110-1b**

Seite/Page 1 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	271 927 12	1	Armaturenblech	Instrument board panel
02	280 261 12	1	LMB Graphikkonsole	LMB console
03	461 507 40	1	Tastenkippsschalter	Push-toggle switch
04	551 038 40	5	Tastenkippsschalter	Push-toggle switch
05	551 036 40	3	Tastenkippsschalter	Push-toggle switch
06	524 991 40	5	Tastenkippsschalter	Push-toggle switch
07	551 040 40	2	Tastenkippsschalter	Push-toggle switch
08	655 114 40	1	Zündstartschalter	Ignition switch
09	973 934 73	1	Ersatzschlüssel	Key
10	224 056 12	1	Alarmgeber	Key switch
11	356 255 40	3	Blindplatte	Blank plate
15	671 555 40	1	Meldeleuchtenmodul	Indicator light modul
16	576 130 40	1	Digitaluhr Standheizung	Timer clock aux. heating
17	356 256 40	4	Druckhaube, rot	Push hood, red
18	356 254 40	4	Meldeleuchte	Indicator light
19	356 156 40	4	Glühlampe	Bulb
21	551 080 40	3	Schlüsseltaster	Key operated push button
24	363 410 40	4	Blindplatte	Blank plate
25	271 932 12	1	Symbolfolie OW	Symbolic foil
26	286 931 12	1	Symbolfolie	Symbolic foil
27	507 049 98	14	Schraube	Screw
28	490 943 40	14	Rosette	Fitting
29	635 842 40	1	Notstop Taster	Emergency switch
30	654 191 40	1	Notstop-Schild	Emergency-off decal
32	001 808 12	1	Notstop-Schalterblock	Emergency, shift block
33	201 319 12	1	Potentiometer	Potentiometer
34	201 321 12	1	Drehknopf	Control knob
35	440 795 40	1	Aufnahmegehäuse	Housing
36	440 800 40	3	Buchsenkontakt	Female contact
37	490 582 40	1	Einbausteckdose	Built-in socket
38	417 386 40	1	Zigaretten-Anzünder	Lighter
39	225 694 12	1	Steckdose	Plug box
40	125 694 99	2	Zylinderschraube	Screw
41	509 858 98	2	Mutter	Nut
42	174 301 12	1	Buchsenabdeckung	Cover
43	272 808 12	1	Speichererweiterung	Memory extention PDM
44	272 809 12	1	Adapter	Adapter
45	621 415 40	24	Glühlampe	Bulb
46	131 977 12	1	Glühlampe	Bulb
			<b>Klimaanlage</b>	<b>Air conditioning</b>
62	201 315 12	1	Schalter	Switch

**Armaturenbrett  
Dash Board**

**168-2110-1b**

Seite/Page 2 / 3

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
63	201 316 12	1	Drehknopf <b>Verfahren von oben</b>	Control knob <b>Drive from superstructure</b>
71	461 507 40	1	Tastenkippschalter	Push-toggle switch
72	515 398 40	1	Symbol "Hundegang"	Symbol "Crab walk"