



168-6025a

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
-	306 520 12	1	1. Innenkasten, kpl.	1st. inner case assy.
01	306 525 12	1	1. Innenkasten SK	1st. inner case, weldment
02	586 699 40	2	Halter, hinten	Retainer, rear
03	306 561 12	1	Halter Backen, links	Retainer shoe, L.H.
04	611 851 40	2	Halter, vorne	Retainer, front
05	306 562 12	1	Halter Backen, rechts	Retainer shoe, R.H.
06	528 004 40	1	Tragrolle	Top roller
07	201 625 12	2	Gleitschuh	Guide shoe
08	307 152 12	4	Platte	Plate
09	307 153 12	2	Platte	Plate
10	611 781 40	2	Gleitstück	Slider
11	528 124 40	2	Gleitbacken	Lining
12	611 848 40	2	Gleitstück	Slider
13	551 052 40	2	Klappstecker	Fore lock
14	509 830 98	8	Schraube	Bolt
15	306 597 12	1	Deckel	Cover
16	509 864 98	4	Mutter	Nut
17	509 832 98	10	Schraube	Bolt
18	350 561 99	2	Schmiernippel	Grease nipple
19	345 044 99	2	Spannstift	Dowel pin
20	510 684 98	2	Schraube	Bolt
21	509 866 98	4	Mutter	Nut
22	510 494 98	8	Scheibe	Washer
23	586 698 40	2	Platte	Plate
24	509 865 98	8	Mutter	Nut
25	511 023 98	4	Schraube	Bolt
28	511 621 98	4	Gewindestift	Threaded pin
29	509 796 98	4	Schraube	Bolt
30	587 267 40	2	Platte	Plate
31	587 403 40	2	Platte	Plate
32	201 651 12	2	Gleitschuh	Guide shoe
33	201 652 12	2	Gleitschuh	Guide shoe
34	201 653 12	2	Gleitschuh	Guide shoe
35	201 654 12	2	Gleitschuh	Guide shoe
36	201 655 12	2	Gleitschuh	Guide shoe
37	201 656 12	2	Gleitschuh	Guide shoe
41	528 029 40	1	Rohr	Pipe
42	504 770 98	2	Kugellager	Ball bearing
43	528 003 40	2	Bolzen	Pin

**1.Innenkasten
1st. Inner Case**

168-6025a

Seite/Page 2 / 2