




177-2110

Seite/Page 1 / 3

| Bild-Nr<br>Fig<br>Fig<br>Fig<br>Fig<br>Bild nr | ET-Nr<br>Part-No<br>No. de Piece<br>No. de Pieza<br>No. del Pezzo<br>Detalj nr | Stückzahl<br>Qty<br>Qte<br>Ctd<br>Qta<br>Antal | Gegenstand<br>Description<br>Designation<br>Descripcion<br>Designazione<br>Benaemning |                                |
|------------------------------------------------|--------------------------------------------------------------------------------|------------------------------------------------|---------------------------------------------------------------------------------------|--------------------------------|
| 01                                             | 671 373 40                                                                     | 1                                              | Armaturenblech                                                                        | Instrument board panel         |
| 02                                             | 000 095 12                                                                     | 1                                              | Meldeleuchtenmodul                                                                    | Indicator light modul          |
| 03                                             | 412 083 12                                                                     | 1                                              | Anzeigedashboard                                                                      | Instrument                     |
| 04                                             | 655 114 40                                                                     | 1                                              | Zündstartschalter                                                                     | Ignition switch                |
| 05                                             | 671 555 40                                                                     | 1                                              | Meldeleuchtenmodul                                                                    | Indicator light modul          |
| 06                                             | 670 895 40                                                                     | 1                                              | Symboleinsätze OW                                                                     | Symbol " insert OW"            |
| 07                                             | 635 842 40                                                                     | 1                                              | Notstop Taster                                                                        | Emergency switch               |
| 08                                             | 654 191 40                                                                     | 1                                              | Notstop-Schild                                                                        | Emergency-off decal            |
| 09                                             | 670 907 40                                                                     | 1                                              | Symbolfolie                                                                           | Symbolic foil                  |
| 11                                             | 576 130 40                                                                     | 1                                              | Digitaluhr Standheizung                                                               | Timer clock aux. heating       |
| 13                                             | 634 096 40                                                                     | 1                                              | Schalter                                                                              | Switch                         |
| 14                                             | 634 097 40                                                                     | 1                                              | Symbol "Gebläse"                                                                      | Symbol "blower"                |
| 15                                             | 363 410 40                                                                     | 9                                              | Blindplatte                                                                           | Blank plate                    |
| 16                                             | 551 036 40                                                                     | 2                                              | Tastentaster                                                                          | Push-toggle switch             |
| 17                                             | 551 040 40                                                                     | 2                                              | Tastentaster                                                                          | Push-toggle switch             |
| 18                                             | 551 038 40                                                                     | 2                                              | Tastentaster                                                                          | Push-toggle switch             |
| 19                                             | 524 991 40                                                                     | 4                                              | Tastentaster                                                                          | Push-toggle switch             |
| 20                                             | 551 081 40                                                                     | 1                                              | Symbol "Scheibenwascher"                                                              | Symbol "Windscreen washing"    |
| 21                                             | 414 509 40                                                                     | 2                                              | Symbol "Scheibenwischer"                                                              | Symbol "Wiper"                 |
| 22                                             | 414 510 40                                                                     | 1                                              | Symbol "Armaturen-<br>beleuchtung"                                                    | Symbol "Instrument<br>lighting |
| 23                                             | 524 948 40                                                                     | 1                                              | Symbol "Arbeitsscheinwerfer<br>vorne"                                                 | Symbol "Spotlight"             |
| 24                                             | 507 049 98                                                                     | 12                                             | Schraube                                                                              | Screw                          |
| 25                                             | 490 943 40                                                                     | 12                                             | Rosette                                                                               | Fitting                        |
| 26                                             | 490 582 40                                                                     | 1                                              | Einbausteckdose                                                                       | Built-in socket                |
| 27                                             | 654 188 40                                                                     | 1                                              | Blindplatte                                                                           | Blankplate                     |
| 29                                             | 131 580 12                                                                     | 1                                              | LMB console                                                                           | LMB console                    |
| 30                                             | 670 909 40                                                                     | 1                                              | Lichtwellenleitung                                                                    | Light wave line                |
| 31                                             | 356 256 40                                                                     | 3                                              | Druckhaube, rot                                                                       | Push hood, red                 |
| 32                                             | 356 254 40                                                                     | 3                                              | Meldeleuchte                                                                          | Indicator light                |
| 33                                             | 356 156 40                                                                     | 3                                              | Glühlampe                                                                             | Bulb                           |
| 34                                             | 551 080 40                                                                     | 3                                              | Schlüsseltaster                                                                       | Key operated push button       |
| 40                                             | 973 934 73                                                                     | 1                                              | Ersatzschlüssel                                                                       | Key                            |
| 41                                             | 621 415 40                                                                     | 10                                             | Glühlampe<br>zu Bild-Nr.: 16-19                                                       | Bulb<br>to fig-no.: 16-19      |
| 42                                             | 420 064 12                                                                     | 17                                             | Glühlampe<br>zu Bild-Nr.: 02+05                                                       | Bulb<br>to fig-no.: 02+05      |
| 43                                             | 435 331 12                                                                     | 1                                              | Kabel                                                                                 | Cable                          |
|                                                |                                                                                |                                                | <b>Klimaanlage</b>                                                                    | <b>Air conditioning</b>        |
| 51                                             | 654 187 40                                                                     | 1                                              | Schalter                                                                              | Switch                         |
| <b>Armaturenblech<br/>Dash Board</b>           |                                                                                |                                                |                                                                                       | <b>177-2110</b>                |
|                                                |                                                                                |                                                |                                                                                       | Seite/Page 2 / 3               |

| Bild-Nr<br>Fig<br>Fig<br>Fig<br>Fig<br>Bild nr                                                        | ET-Nr<br>Part-No<br>No. de Piece<br>No. de Pieza<br>No. del Pezzo<br>Detalj nr | Stückzahl<br>Qty<br>Qte<br>Ctd<br>Qta<br>Antal | Gegenstand<br>Description<br>Designation<br>Descripcion<br>Designazione<br>Benaemning |                                                                |
|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|------------------------------------------------|---------------------------------------------------------------------------------------|----------------------------------------------------------------|
| 52                                                                                                    | 654 189 40                                                                     | 1                                              | Symbol "Klima"<br><b>Abstützen von oben</b>                                           | Symbol "Air condition"<br><b>To set on outriggers from top</b> |
| 61                                                                                                    | 551 038 40                                                                     | 4                                              | Tastenkippschalter                                                                    | Push-toggle switch                                             |
| 62                                                                                                    | 545 228 40                                                                     | 1                                              | Symboleinsätze                                                                        | Set of foils                                                   |
| 63                                                                                                    | 551 036 40                                                                     | 1                                              | Tastenkippschalter                                                                    | Push-toggle switch                                             |
| 64                                                                                                    | 000 201 12                                                                     | 1                                              | Tastenkippschalter                                                                    | Push-toggle switch                                             |
| 65                                                                                                    | 461 787 40                                                                     | 1                                              | Symbol "Motorstop"                                                                    | Symbol "Engine stop"                                           |
| <div> <div>Armaturenboard<br/>Dash Board</div> <div>177-2110</div> <div>Seite/Page 3 / 3</div> </div> |                                                                                |                                                |                                                                                       |                                                                |