



<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
01	551 036 40	3	Tastenkippshalter	Push-toggle switch
02	461 507 40	1	Tastenkippshalter	Push-toggle switch
03	551 038 40	2	Tastenkippshalter	Push-toggle switch
04	133 620 12	1	Symboleinsätze	Set of foils
05	515 743 40	4	Relais	Relay
06	162 755 12	1	Display	Display
07	654 751 40	2	Relais	Relay
08	169 226 12	1	Abdeckplatte	Covering plate

**Abstützen von Oben  
To Set On Outriggers From Top**

**177-2196a**

Seite/Page 2 / 2