



Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	131 556 12	1	Frontplatte	Front plate
03	507 049 98	16	Schraube	Screw
04	490 943 40	16	Rosette	Fitting
05	634 094 40	1	Zündstartschalter	Ignition switch
06	414 582 40	1	Potentiometer	Potentiometer
07	634 955 40	1	Potentiometer	Potentiometer
08	001 278 12	2	Drehknopf	Control knob
09	001 279 12	2	Mutterabdeckung	Nut covering
10	001 280 12	2	Deckel	Cover
11	002 004 12	2	Schlitzmutter	Nut
12	551 036 40	1	Tastenkippschalter	Push-toggle switch
13	524 991 40	7	Tastenkoppschalter	Push-toggle switch
14	551 039 40	2	Tastenkippschalter	Push-toggle switch
15	551 040 40	2	Tastenkippschalter	Push-toggle switch
16	363 410 40	4	Blindplatte	Blank plate
18	131 705 12	1	Symbolplatte	Symbole plate
19	417 386 40	1	Zigarettenanzünder	Cigarette lighter
20	490 582 40	1	Einbausteckdose	Built in socket
21	001 033 12	1	Flanschdose 8-pol.	Plug-in socket
22	001 034 12	1	Staubkappe	Dust cap
23	001 035 12	8	Buchsenkontakt	Female contact
24	318 167 99	4	Schraube	Screw
25	509 858 98	4	Mutter	Nut
26	654 816 40	1	Diagnosedose	Diagnosis box
27	654 825 40	1	Staubkappe	Dust cap
28	654 826 40	1	Befestigungsring	Fixing ring
29	654 827 40	1	Abstandsscheibe	Spacer shim
30	654 814 40	14	Kontaktbuchse	Female contact
31	604 460 40	16	Steckhülsegehäuse	Female housing
32	604 459 40	160	Doppelfederkontakt	Double spring contact
33	634 095 40	1	Stecker	Plug
34	057 251 40	6	Steckhülse	Sleeve