



187-2110b

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal	Gegenstand Description Designation Descripcion Designazione Benaemning	
01	000 588 12	1	Windgeschwindigkeitsanzeige	Anemometer
02	130 402 12	1	Armaturenblech	Instrument board panel
03	507 049 98	6	Schraube	Screw
04	490 943 40	6	Rosette	Fitting
05	634 094 40	1	Zündstartschalter	Ignition switch
06	634 095 40	1	Stecker	Plug
07	057 251 40	5	Steckhülse	Sleeve
08	551 023 40	1	Potentiometer	Potentiometer
09	440 744 40	2	Zeigerknopf	Knob
10	621 217 40	1	Leuchtdrucktaster	Luminous push switch
11	621 216 40	1	Pilzdruckhaube rot	Mushroom push hood
12	635 072 40	11	Blindplatte	Blank plate
13	635 068 40	58	Frontrahmen	Front panel
14	356 156 40	55	Glühlampe	Bulb
15	001 635 12	10	Meldeleuchtensvorsatz	Indicator light adapter
16	001 636 12	23	Leuchtdrucktastervorsatz	Luminous touch contact
17	001 637 12	21	Leuchtdruckschaltevorsatz	Luminous push switch
18	635 060 40	3	Schlüsseltaster	Key operated push button
20	635 069 40	12	Sprungschalterelement	Quick-break switch element
21	635 070 40	2	Sprungschalterelement	Quick-break switch element
22	635 071 40	33	Sprungschalterelement	Quick-break switch element
23	001 638 12	5	Druckhaube rot	Push hood red
24	001 639 12	10	Druckhaube gelb	Push hood yellow
25	001 640 12	9	Druckhaube grün	Push hood green
26	001 641 12	7	Druckhaube blau	Push hood blue
27	001 642 12	23	Druckhaube klar	Push hood clear
28	256 587 40	1	Alarmgeber	Alarm transmitter
29	490 582 40	1	Einbausteckdose	Built-in socket
30	369 200 40	-	Kabel 14x1,(Länge angeben)	Cable,(length required)
31	001 514 12	-	Kabel 65x1,(Länge angeben)	Cable,(length required)
32	131 748 12	1	Symbolfolie	Symbolic foil
33	414 582 40	1	Potentiometer	Potentiometer

**Armaturentafel, vorne
Instrument panel, front**

187-2110b

Seite/Page 2 / 2