



187-6112

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	110 777 12	1	Wippstütze vorne	Luffing mast, front side
01	111 168 12	1	Wippstütze SK	Luffing mast (weldment)
02	113 848 12	2	Buchse	Bushing
03	350 562 99	2	Schmiernippel	Grease nipple
04	151 178 99	1	Scheibe	Washer
05	342 121 99	1	Splint	Cotter pin
06	113 847 12	1	Bolzen	Pin
07	115 718 12	1	Bolzen	Pin
08	342 540 99	2	Sicherungsring	Circlip
09	115 720 12	1	Walze	Roll
10	511 617 98	2	Klappstecker	Fore lock
11	601 426 40	2	Bolzen	Pin
12	631 808 40	1	Seilrolle einschl. Bild-Nr. 31-33	Sheave incl. fig-nos. 31-33
14	113 845 12	1	Achse	Axle
15	001 039 12	1	Begehung	Catwalks
16	000 642 12	1	Begehung	Catwalks
17	001 040 12	1	Begehung	Catwalks
18	880 447 40	4	Bügel	Yoke
19	321 199 99	8	Schraube	Screw
20	515 596 40	9	Olive	Olive
21	151 182 99	1	Schraube	Screw
22	307 429 99	14	Schraube	Screw
23	340 684 99	29	Scheibe	Washer
24	509 870 98	15	Mutter	Nut
31	631 803 40	1	Seilrolle	Sheave
32	002 023 98	1	Lager	Bearing
33	505 940 98	2	Sicherungsring	Snap ring

Wippstütze, vorne
Luffing mast, front side

187-6112

Seite/Page 2 / 2