



**188-1800**

Seite/Page 1 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	446 230 40	1	Hydrauliköltank (SK)	Hydraulic oil tank
02	446 680 40	1	Pralltopf	Impactor
03	307 775 99	4	Schraube	Bolt
04	346 500 99	4	Federring	Lock washer
05	000 209 98	1	O-Ring	O-ring
06	324 650 40	1	Kupplungsmuffe	Coupling sleeve
07	336 801 40	3	Deckel	Cover
08	324 402 99	18	Gewindestift	Threaded pin
09	332 111 99	18	Mutter	Nut
10	255 572 40	3	O-Ring	O-ring
11	339 865 99	3	Dichtring	Seal ring
12	321 805 99	3	Hutmutter	Cap nut
13	006 857 98	3	Druckfeder	Compression spring
14	346 510 99	18	Federring	Lock washer
15	336 654 40	3	Spanndeckel	Stretch cover
16	006 709 98	3	O-Ring	O-ring
17	-	3	Filter siehe EL-Blatt 90-0049	Filter see page 90-0049
18	500 310 98	6	Gewindestift	Threaded pin
19	334 678 99	6	Mutter	Nut
20	308 562 99	3	Schraube	Bolt
21	323 147 40	1	Deckel	Cover
22	208 890 40	1	Staubmuffe	Dust muff
23	255 774 40	1	Luftfilter	Air cleaner
24	415 850 40	1	Ausgleichsbehälter	Expansion tank
25	447 076 40	1	Rohrleitung	Pipe assy.
26	440 630 40	1	Durchgangsventil	Valve
27	371 955 99	1	Verschraubung	Union
28	506 163 98	1	Verschraubung	Union
29	447 078 40	1	Schlauch	Hose
30	005 880 98	2	Schelle	Clamp
31	007 107 98	2	Verschraubung	Union
32	447 091 40	1	Tecalan-Rohr	Plastic pipe
33	447 090 40	1	Spannband	Restraining strap
34	332 113 99	4	Mutter	Nut
35	447 088 40	1	Sammelrohr	Header
36	447 130 40	1	Sammelrohr	Header
37	447 140 40	1	Flansch	Flange
38	202 985 40	1	Spiralschlauch	Spiral hose
39	005 868 98	2	Schelle	Clamp

**Hydraulikölbehälter  
Hydraulic Oil Tank**

**188-1800**

Seite/Page 2 / 3

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
40	302 101 99	1	Schraube	Screw
40	302 102 99	1	Schraube ab Bau-Nr. 88 002	Screw from s/no: 88 002
41	346 500 99	1	Federring	Lock washer
42	307 802 99	8	Schraube	Bolt
43	447 144 40	1	Dichtung	Seal
44	500 623 98	2	Schraube	Bolt
45	346 510 99	2	Federring	Lock washer

**Hydraulikölbehälter**  
**Hydraulic Oil Tank**

**188-1800**

Seite/Page 3 / 3