



190-1925-1

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	230 050 40	1	Ventilkonsole (Turmkabine)	Valve console (tower cab)
02	332 111 99	6	Mutter	Nut
03	346 510 99	6	Federring	Lock washer
04	307 754 99	4	Schraube	Screw
05	307 756 99	3	Schraube	Screw
06	188 312 40	1	Fußbetätigung	Foot control
07	342 057 99	2	Splint	Split pin
08	335 178 99	1	Bolzen	Bolt
09	187 831 40	1	Gabelkopf	Clevis
10	332 113 99	1	Mutter	Nut
14	321 174 40	1	Gelenkstück	Joint
15	-	1	Druckregelventil mit Gabel siehe EL-Blatt 108-1926	Pressure control valve with fork see page 108-1926
16	307 752 99	2	Schraube	Screw
17	340 464 99	2	Scheibe	Washer
20	247 992 40	1	Ventilkonsole (Fahrerstand)	Valve console (tower cab)
25	956 785 00	1	E-Päckchen zu Bild-Nr. 06	Spare part kit to fig-no: 06
30	352 875 40	1	Federbock, kpl. bestehend aus Bild-Nr. 31-38	Spring block consist. of fig-nos: 31-38
31	352 876 40	1	Feder, kpl. bestehend aus Bild-Nr. 35-38	Spring, assy. consist. of fig-nos: 35-38
32	352 877 40	2	Rohr	Pipe
33	335 131 99	1	Bolzen	Pin
34	342 032 99	2	Splint	Cotter pin
35	352 878 40	1	Platte	Plate
36	352 879 40	1	Platte	Plate
37	504 753 98	1	Druckfeder	Compression spring
38	319 415 99	4	Schraube	Screw

Drehwerksbremsbetätigung
Swing gear brake control

190-1925-1

Seite/Page 2 / 2