



202-3664a

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaemning |
|--|--|---|---|--|
| | | | | 402 022 40 |
| 01 | 402 043 40 | 1 | Lenkhebel, unten | Steering lever, below |
| 02 | 402 034 40 | 1 | Lenkhebel, oben | Steering lever, top |
| 03 | 387 889 40 | 2 | Buchse | Bush |
| 04 | 387 891 40 | 1 | Nutmutter | Groove nut |
| 06 | 363 896 40 | 2 | Gleitlager | Bearing sleever |
| 09 | 350 561 99 | 1 | Schmiernippel | Fitting |
| 12 | - | 1 | Federspeicher siehe EL-Blatt 90-1719 | Spring accumulator see page 90-1719 |
| 13 | 324 146 40 | 1 | Druckschalter | Pressure switch |
| 14 | 302 548 99 | 4 | Schraube | Screw |
| 15 | 502 504 98 | 4 | Scheibe | Washer |
| 16 | 334 695 99 | 4 | Mutter | Nut |
| 17 | 349 003 40 | 1 | Stößelschalter | Tappet switch |
| Lenkhebel 2 (Hundegang) Steering Lever 2nd (Crab Walk Gear) | | | | 202-3664a Seite/Page 2/2 |