



219-3620a

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
04	-	1	Lenktriebachse, s. EL-Blatt "Achse 4-Gruppe 36"	Steering drive axle see page "axle 4-group 36"
05	-	1	Lenktriebachse, s. EL-Blatt "Achse 5-Gruppe 36"	Steering drive axle see page "axle 5-group 36"
06	324 146 40	2	Stößelschalter	Tappet switch
-	263 583 40	2	Stecker zu Bild-Nr. 06	Plug to fig-no. 06
07	-	2	Federungszyylinder siehe EL-Blatt 90-1716	Resilient cylinder see page 90-1716
08	350 852 40	4	Bolzen	Pin
09	350 853 40	4	Bolzen	Pin
10	207 428 40	4	Distanzring	Spacer
11	340 625 99	12	Scheibe	Washer
12	342 540 99	12	Sicherungsring	Circlip
13	350 854 40	8	Distanzring	Spacer
14	-	2	s. EL-Blatt "Federungszyylinder" <b>ab Bau-Nr. 37 117</b>	see page "resilient cylinder" <b>from s/no. 37 117 up</b>
14	-	1	s. EL-Blatt "Federungszyylinder, links"	see page "resilient cylinder l.h."
15	504 812 98	16	Skt.-Schraube	Bolt
16	504 813 98	16	Skt.-Schraube	Bolt
17	-	3	Lenkzylinder siehe EL-Blatt 90-1271	Steering cylinder see page 90-1271
18	243 434 40	6	Kugelgelenkkopf	Knuckle
-	690 457 73	6	Staubkappe zum Kugelgelenkkopf	Dust cap for knuckle
-	553 810 40	-	Niveauanzeiger ab Bau-Nr. 37 224	Level indicator from s/no: 37 224
-	332 351 99	-	Mutter zu Niveauanzeiger	Nut to level indicator
23	387 831 40	4	Achsstrebe	Axle brace
23	621 667 40	4	Achsstrebe ab 37 195	Axle brace, from S/No. 37 195
-	780 194 73	8	Reparatursatz zu 387 831 40	Repair kit to 387 831 40
24	387 834 40	4	Achsstrebe	Axle brace
24	621 670 40	4	Achsstrebe ab 37 195 <b>ab Bau-Nr. 37 117</b>	Axle brace from S/No. 37 195 <b>from s/no. 37 117 up</b>
31	-	1	s. EL-Blatt "Federungszyylinder, rechts"	see page "resilient cylinder r.h."

**Achseinbau Achse 4 + 5**  
**Axle Arrangement 4 + 5**

**219-3620a**

Seite/Page 2/2