



219-3664

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	387 881 40	1	Außenhebel	Outer lever
02	387 886 40	1	Innenhebel	Inner lever
03	363 896 40	2	Gleitlager	Bearing-sleeve
04	387 889 40	2	Ring	Ring
05	387 891 40	1	Nutmutter	Groove nut
06	350 561 99	1	Schmiernippel	Grease nipple
07	-	1	Federspeicher siehe EL-Blatt 90-1719	Spring accumulator see page 90-1719
08	324 146 40	1	Druckschalter, Öffner (bei Bestellung angeben)	Pressure switch, NC (indicate on order)
09	302 548 99	4	Skt.-Schraube	Bolt
10	334 695 40	4	Skt.-Mutter	Nut
11	502 504 98	4	Scheibe	Washer
11	316 211 99	4	Scheibe, ab 37 195	Washer, from S/No. 37 195
12	363 866 40	2	Leiste	Strip
13	349 003 40	1	Druckschalter, Schließer (bei Bestellung angeben)	Pressure switch, NO (indicate on order)

Lenkhebel - Hundegang
Steering Lever - Crab Walk

219-3664

Seite/Page 2/2