



220-1915

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	192 514 40	1	Lenkrad	Steering wheel
01	551 343 40	1	Lenkrad, ab 98 074	Steering wheel, from 98 074 up
02	192 515 40	1	Signalknopf	Signal knob
02	515 897 40	1	Signalknopf, ab 98 074	Signal knob, from 98 074 up
03	-	1	Winkelgetriebe siehe EL-Blatt 90-4411	Angle drive see page 90-4411
03	551 106 40	1	Winkelgetriebe, ab 98 074	Angle drive, from 98 074 up
04	307 807 99	8	Schraube	Bolt
05	334 682 99	8	Mutter	Nut
06	338 154 40	1	Konsole	Console
07	307 597 99	4	Schraube	Bolt
08	334 673 99	4	Mutter	Nut
09	192 704 40	1	Faltenbalg	Bellows
10	340 464 99	4	Scheibe	Washer
11	192 519 40	4	Kreuzgelenk	Universal joint
12	192 520 40	8	Schraube	Screw
13	192 521 40	8	Mutter	Nut
14	319 576 99	4	Schraube	Screw
18	315 577 40	1	Teleskopwelle	Telescopic shaft
21	295 479 40	1	Lenkstockhebel	Drop arm
22	006 508 98	1	Spannschelle	Clip
23	192 314 40	1	Schelle	Clip
24	319 256 99	2	Skt.-Schraube	Bolt
-	334 678 99	2	Mutter (zu Bild-Nr. 24)	Nut (to fig-no: 24)
26	192 517 40	1	Moosgummi	Cellular rubber
27	192 518 40	1	Gummi	Rubber
30	388 033 40	1	Hydro-Lenkung	Power steering
-	778 844 73	1	Dichtsatz zu Bild-Nr. 30	Seal kit to fig-no: 30
Lenkungseinbau				220-1915
Steering Assy. Mounting				Seite/Page 2/2