


00



222-2112a

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	662 670 40	1	Armaturenbrett 3, kpl.	Dash board 3 assy.
01	645 131 40	1	Armaturenblech III	Instrument board panel
02	415 847 40	1	Bedienungsschalter	Operating switch
03	263 324 40	2	Halteklammer	Clamp
04	263 322 40	4	Spreizscheibe	Shim
05	461 507 40	3	Tastenkippsschalter	Push-toggle switch
06	363 410 40	13	Blindplatte	Blank plate
07	522 372 40	6	Meldeleuchte	Indicator light
08	663 152 40	1	Symbolplatte	Symbol plate
10	490 943 40	4	Rosette mit Schraube	Fitting with bolt
11	507 049 98	4	Senkschraube	Countersunk screw
12	551 038 40	4	Tastenkippsschalter	Push-toggle switch
13	634 860 40	1	Tastenkippsschalter	Push-toggle switch
14	256 587 40	1	Alarmgeber	Alarm transmitter
15	551 039 40	1	Tastenkippsschalter	Push-toggle switch
16	417 386 40	1	Zigaretten-Anzünder	Cigarette lighter
17	621 734 40	2	Flachsteckergehäuse	Flat blade housing
18	440 802 40	4	Flachstecker	Tab
19	414 755 40	1	Tastenkippsschalter	Push-toggle switch
20	461 230 40	1	Tastenkippsschalter	Push-toggle switch
21	-	1	Taster	Tip switch

**Armaturenbrett III
Dash Board III**

222-2112a

Seite/Page 2 / 2