



223-1800a

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaemning |
|-------------------------------------------------------|---------------------------------------------------------------------------------------|-------------------------------------------------------|------------------------------------------|----------------------------------------------------------------------------------------------|
| 00 | 450 480 40 | 1 | Hydrauliköltank, kpl. | Hydraulic oil tank, assy. |
| 01 | 450 481 40 | 1 | Hydrauliköltank (SK) | Hydraulic oil tank |
| 02 | 450 472 40 | 2 | Spannband | Restraining strap |
| 03 | - | 2 | Rücklauffilter siehe EL-Blatt 90-0603 | Return oil filter see page 90-0603 |
| 04 | 007 083 98 | 2 | O-Ring | O-ring |
| 05 | 334 673 99 | 14 | Mutter | Nut |
| 06 | 338 493 40 | 1 | Deckel | Cover |
| 07 | 372 300 99 | 2 | Verschraubung | Union |
| 08 | 137 296 40 | 2 | Einsteckhülse | Plug-in sleeve |
| 11 | 081 495 40 | 2 | Kupplungsmuffe | Coupling sleeve |
| 12 | 339 998 99 | 2 | Dichtring | Seal ring |
| 13 | 081 496 40 | 2 | Schutzkappe | Protection cap |
| 14 | 334 678 99 | 4 | Mutter | Nut |
| 15 | 340 465 99 | 4 | Scheibe | Washer |
| 17 | - | 1 | Einfüllfilter siehe EL-Blatt 90-0013 | Filler see page 90-0013 |
| - | - | - | Rohre siehe EL-Blatt 90-9959 | Pipes see page 90-9959 |

Hydrauliköltank
Hydraulic Oil Tank

223-1800a

Seite/Page 2 / 2