



Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	295 380 40	1	Tachograph	Tachograph
02	263 130 40	1	Kombi-Instrument	Multiple indication assy.
03	770 722 00	1	Temperatur Anzeige - Getriebe	Temperature indicator - gear box
04	208 933 40	1	Zündstartschalter	Ignition switch
05	385 213 40	1	Zigaretten-Anzünder	Cigarette lighter
06	415 847 40	1	Bedienungsschalter - Heizung	Operating switch - heater
07	263 324 40	2	Halteklammern	Clamp
08	263 322 40	4	Spreizscheiben	Shim
09	356 254 40	20	Meldeleuchte	Signal light
10	356 256 40	9	Druckhaube, rot	Push hood, red
11	356 257 40	14	Druckhaube, gelb	Push hood, yellow
12	414 245 40	1	Druckhaube, blau	Push hood, blue
13	368 183 40	2	Druckhaube, grün	Push hood, green
14	356 156 40	26	Glühlampe	Bulb
15	356 255 40	27	Blindplatte	Blank plate
16	363 406 40	1	Tastenkippsschalter - Lichtschalter	Push-toggle switch - lighting
17	363 407 40	1	Tastenkippsschalter - Nebelschlußleuchte	Push-toggle switch - fog tail light
18	363 407 40	1	Tastenkippsschalter - Rundumleuchte	Push-toggle switch - omnidirect. light
19	363 414 40	1	Tastenkippsschalter - Motorstop	Push-toggle switch - engine- stop
20	363 408 40	1	Tastenkippsschalter - Heizung/Lüftung	Push-toggle switch - heater/fan
21	363 409 40	1	Tastenkippsschalter - Längssperre	Push-toggle switch - straight-lock
22	363 409 40	1	Tastenkippsschalter - Quersperre	Push-toggle switch - cross-lock
23	414 018 40	1	Tastenkippsschalter - Warnblinkschalter	Push-toggle switch - hazard switch
24	414 755 40	1	Tastenkippsschalter - Scheibenwischer	Push-toggle switch - wiper
25	363 426 40	1	Symbol	Symbol
26	363 419 40	1	Symbol	Symbol
27	363 420 40	1	Symbol	Symbol
28	363 418 40	1	Symbol	Symbol
29	363 421 40	1	Symbol	Symbol
30	363 417 40	1	Symbol	Symbol
31	364 140 40	1	Symbol	Symbol

**Armaturenbrett  
Instrument Panel**

**223-2110**

Seite/Page 2 / 3

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
32	440 543 40	1	Symbol	Symbol
33	363 410 40	9	Blende	Blank plate
34	318 576 40	20	Schraube	Screw
35	418 991 40	1	Symbolfolie	Symbolic foil
36	368 044 40	6	Leuchtdrucktaster	Luminous touch contact
37	356 258 40	2	Schlüsselschalter	Key switch
38	256 587 40	1	Alarmsummer	Warning buzzer
39	440 394 40	3	Leuchtdiode, rot	Diode, red
40	440 393 40	3	Druckhaube, rot	Push hood, red
41	414 756 40	1	Symbol	Symbol
42	442 738 40	1	Blende	Blank plate
43	318 576 40	2	Schraube	Screw

**Armaturenbrett  
Instrument Panel**

**223-2110**

Seite/Page 3 / 3