



**223-2110b**

Bild- Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	295 380 40	1	Tachograph	Tachograph
02	263 130 40	1	Kombi-Instrument	Multiple indication assy.
03	770 722	1	Temperaturanzeige - Getriebe	Temperature indicator - gear box
04	208 933 40	1	Zündstartschalter	Ignition switch
05	385 213 40	1	Zigaretten-Anzünder	Cigarette lighter
06	415 847 40	1	Bedienungsschalter - Heizung	Operating switch - heater
07	263 324 40	2	Halteklammern	Clamp
08	263 322 40	4	Spreizscheiben	Shim
09	356 254 40	20	Meldeleuchte	Signal light
10	356 256 40	9	Druckhaube, rot	Push hood, red
11	356 257 40	16	Druckhaube, gelb	Push hood, yellow
12	414 245 40	1	Druckhaube, blau	Push hood, blue
13	368 183 40	3	Druckhaube, grün	Push hood, green
14	356 156 40	29	Glühlampe	Bulb
15	356 255 40	25	Blindplatte	Blank plate
16	363 406 40	1	Tastenkippsschalter - Lichtschalter	Push-toggle switch - lighting
17	363 407 40	1	Tastenkippsschalter - Nebel- schlußleuchte	Push-toggle switch - fog tail light
18	363 407 40	1	Tastenkippsschalter - Rundum- leuchte	Push-toggle switch - omnidirect. light
19	363 414 40	1	Tastenkippsschalter - Motorstop	Push-toggle switch - engine- stop
20	363 408 40	1	Tastenkippsschalter - Heizung/ Lüftung	Push-toggle switch - heater/fan
21	363 409 40	1	Tastenkippsschalter - Längs- sperre	Push-toggle switch - straight-lock
22	363 409 40	1	Tastenkippsschalter - Quer- sperre	Push-toggle switch - cross-lock
23	414 018 40	1	Tastenkippsschalter - Warnblinkschalter	Push-toggle switch - hazard switch
24	414 755 40	1	Tastenkippsschalter - Scheibenwischer	Push-toggle switch - wiper
25	363 426 40	1	Symbol	Symbol
26	461 751 40	1	Symbol	Symbol
27	461 750 40	1	Symbol	Symbol
28	461 749 40	1	Symbol	Symbol
29	461 786 40	1	Symbol	Symbol
30	363 417 40	1	Symbol	Symbol
31	364 140 40	1	Symbol	Symbol
32	461 787 40	1	Symbol	Symbol

**Armaturrenbrett  
Instrument Panel**

**223-2110b**

Seite/Page 2 / 3

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
33	363 410 40	9	Blende	Blank plate
34	507 182 98	20	Schraube	Screw
35	455 869 40	1	Symbolfolie	Symbolic foil
36	368 044 40	8	Leuchtdrucktaster	Luminous touch contact
37	356 258 40	2	Schlüsselschalter	Key switch
38	256 587 40	1	Alarmsummer	Warning buzzer
39	440 394 40	3	Leuchtdiode, rot	Diode, red
40	440 393 40	3	Druckhaube, rot	Push hood, red
41	414 756 40	1	Symbol	Symbol
42	455 065 40	1	Blende	Blank plate
43	507 049 98	2	Schraube	Screw
44	461 507 40	1	Tastenkippeschalter (Japanausführung)	Push-toggle switch (Japan-design)
45	461 957 40	1	Symbol (Japanausführung)	Symbol (Japan-design)
46	461 280 40	1	Leuchtdrucktaster	Luminous touch contact

**Armaturrenbrett  
Instrument Panel**

**223-2110b**

Seite/Page 3 / 3