



223-3600

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	-	1	Achse, s. EL-Blatt "Lenkachse 1. Achse"	Axle, see page "Steering axle 1st axle"
02	-	2	Lenkzylinder, s. EL-Blatt "Lenkzylinder 1. Achse"	Steering cylinder, see page "Steering cylinder 1st axle"
03	-	1	Federungszyylinder, s. EL-Blatt "Federungszyylinder 1. Achse links"	Resilient cylinder, see page "Resilient cylinder 1st. axle l.h."
04	-	1	Federungszyylinder, s. EL-Blatt "Federungszyylinder 1. Achse rechts"	Resilient cylinder, see page "Resilient cylinder 1st. axle r.h."
05	402 016 40	4	Achsstrebe	Axle brace
06	338 066 40	1	Niveauanzeiger	Level indicator
07	350 852 40	2	Bolzen	Pin
08	350 853 40	2	Bolzen	Pin
09	207 428 40	2	Distanzring	Spacer
10	340 625 40	6	Scheibe	Washer
11	342 540 99	6	Sicherungsring	Circlip
12	350 854 40	4	Distanzring	Spacer
13	504 993 98	4	Schraube	Bolt
14	504 996 98	4	Mutter	Nut
15	505 355 98	4	Schraube	Bolt
16	504 812 98	8	Schraube	Bolt
17	450 620 40	4	Kugelgelenkkopf	Knuckle

Achseinbau 1. Achse - 18x8 und 18x10
Axle Mounting 1st. Axle - 18x8 and 18x10

223-3600

Seite/Page 2/2