



**286-6016**

Seite/Page 1 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaeming
01	161 999 12	1	3. Innenkasten, SK	3. Inner case
02	616 270 40	1	Halter hinten	Retainer rear
03	616 271 40	1	Halter	Retainer
04	612 402 40	1	"Hubendschalter" s. EL-Blatt 171-6225b	"Hoist limit switch" see page 171-6225b
05	589 308 40	5	Seilrolle kompl.	Sheave assy.
06	616 586 40	2	Gleitbacke	Lining
07	616 593 40	2	Gleitstück	Slider
08	616 274 40	2	Blech	Plate
09	345 044 99	2	Spannstift	Dowel pin
10	350 561 99	2	Kegelschmiernippel	Grease nipple
11	514 037 98	4	Schraube	Bolt
12	616 279 40	1	Bolzen	Pin
13	616 284 40	1	Deckel, kpl.	Cover assy.
15	509 794 98	2	Schraube	Bolt
16	616 287 40	2	Bolzen	Pin
17	551 052 40	2	Sicherheitsklappstecker	Safety pin
18	616 461 40	2	Deckel	Cover
20	654 962 40	4	Niet	Rivet
22	616 482 40	1	Achse	Axle
23	616 280 40	1	Bolzen	Pin
24	616 281 40	1	Achshalter	Axle stirrup
25	509 828 98	2	Schraube	Bolt
26	591 653 40	2	Blech	Plate
27	616 484 40	1	Rohr	Pipe
28	616 293 40	2	Rohr	Pipe
29	513 155 98	1	Bolzen	Pin
30	551 053 40	2	Sicherheitsklappstecker	Safety pin
31	509 887 98	1	Sicherungsfeder	Locking spring
32	587 267 40	2	Blech S=15 mm	Plate
33	509 795 98	4	Schraube	Bolt
34	587 268 40	4	Blech S=2 mm	Plate
35	587 403 40	2	Blech S=5 mm	Plate
36	587 404 40	2	Blech S=6 mm	Plate
37	587 347 40	2	Blech S=10 mm	Plate
38	509 422 98	1	Gewindestift	Threaded pin
39	509 867 98	1	Mutter	Nut
40	509 772 98	4	Schraube	Screw
41	616 294 40	1	Rohr	Pipe
42	511 621 98	2	Gewindestift	Threaded pin
43	509 865 98	2	Mutter	Nut

**3. Innenkasten mit Rollenkopf  
3. Inner Case with Sheave Head**

**286-6016**

Seite/Page 2 / 3

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
44	668 263 40	2	Ringblech	Plate
45	616 485 40	1	Platte	Plate
46	509 793 40	12	Schraube	Bolt
47	654 412 40	2	Buchse	Bushing
61	589 309 40	1	Seilrolle	Sheave
62	002 925 98	1	Zylinderrollenlager	Cylindrical roller bearing
63	509 551 98	2	Sprengring	Snap ring

**3. Innenkasten mit Rollenkopf**  
**3. Inner Case with Sheave Head**

**286-6016**

Seite/Page 3 / 3