


Wippwerk  
luffing gear 2



52-1655

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
01	256 977 40	1	Wechselventil	Shuttle valve
02	226 480 40	1	Drosselrückschlagventil	Throttle check valve
04	153 646 40	1	Kupplung	Coupling
05	339 884 99	1	Kupferring	Copper ring
06	004 029 98	1	Verschraubung	Union
07	372 427 99	1	Verschraubung	Union
09	370 313 99	2	Verschraubung	Union
10	255 694 40	1	Verschlussschraube	Plug
11	371 452 99	3	Verschraubung	Union
13	372 613 99	3	Verschraubung	Union
15	373 758 99	1	Verschraubung	Union
16	372 899 99	1	Verschraubung	Union
18	-	1	Schlauch NW 10x1600 s. EL-Blatt 52-1650 /115	Hose see page 52-1650 /115
20	372 373 99	1	Verschraubung	Union
21	372 895 99	1	Verschraubung	Union
23	-	1	Schlauch NW 10x3200 s. EL-Blatt 52-1650 /116	Hose see page 52-1650 /116
25	-	1	Schlauch NW 12x1250 s. EL-Blatt 52-1650 /97	Hose see page 52-1650 /97
26	-	1	Schlauch NW 10x1300 s. EL-Blatt 52-1650 /117	Hose see page 52-1650 /117
27	-	1	Schlauch NW 10x1650 s. EL-Blatt 52-1650 /118	Hose see page 52-1650 /118
28	-	1	Schlauch NW 10x2000 s. EL-Blatt 52-1650 /119	Hose see page 52-1650 /119
29	372 993 99	1	Verschraubung	Union
30	372 996 99	1	Verschraubung	Union
31	372 185 99	2	Verschraubung	Union
32	372 462 99	1	Verschraubung	Union