


Betrieb SW, SW/LW, SWSL, SWSL/LWSL



Betrieb SH; SH/LH; SSL; SSL/LSL




Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	888 451 40	1	Kabel Zuleitung LMB	Cable
02	888 452 40	1	Kabeltrommel	Cable drum
03	888 453 40	1	Kabel Kraftgeber Runner	Cable force transmitter runner
04	888 454 40	1	Kabel Hubendschalter Runner	Cable hoist limit switch