



58-6029

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	583 500 40	1	Anschlußkopf kpl.	Head adapter
01	583 500 40	1	Anschlußkopf SK	Head adapter (weldment)
02	583 546 40	2	Lasche kpl.	Shackle assy.
03	583 555 40	2	Lasche kpl.	Shackle assy.
04	583 551 40	1	Lasche kpl.	Shackle assy.
05	583 549 40	1	Bolzen	Pin
06	508 207 40	2	Bolzen	Pin
07	507 773 98	4	Steckbolzen	Socket pin
08	504 182 98	2	Steckbolzen	Socket pin
09	510 454 98	2	Bolzen	Pin
10	583 556 40	2	Achshalter	Axle stirrup
11	460 878 40	8	Blech	Plate
12	292 556 40	2	Wellenendscheibe	End plate
13	505 909 98	6	Sicherungsbolzen	Lock pin
14	505 908 98	2	Sicherungsbolzen	Lock pin
15	007 266 98	8	Sicherungsfeder	Locking spring
16	583 557 40	2	Buchse	Bushing
17	551 351 40	2	Stabil-Rost	Grid
18	537 493 40	4	Distanzrohr	Distance sleeve
19	307 924 99	4	Schraube	Bolt
20	307 843 99	4	Schraube	Bolt
21	307 756 99	8	Schraube	Bolt
22	334 690 99	8	Mutter	Nut
23	350 763 99	16	Scheibe	Disc
24	350 562 99	2	Schmiernippel	Grease nipple
25	490 036 40	9	Gummihülse	Grommet
26	490 037 40	9	Bügel	Yoke
27	506 758 98	9	Flügelmutter	Wing nut
34	583 548 40	4	Buchse	Bushing
35	350 562 99	4	Schmiernippel	Grease nipple
39	508 058 98	1	Gelenklager	Swing support
40	342 693 99	1	Sicherungsring	Circlip

**Anschlußkopf
Head Adapter**

58-6029

Seite/Page 2/2