



58-6070

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaemning |
|---|--|---|--|--|
| 00 | 583 929 40 | 1 | Wipptraverse kpl. | Flying bridle assy. |
| 01 | - | 1 | Wipptraverse oben kpl. s. EL-Blatt 58-6073 | Flying bridle top assy. see page 58-6073 |
| 02 | - | 1 | Wipptraverse unten kpl. s. EL-Blatt 58-6076 | Flying bridle lower assy. see page 58-6076 |
| 03 | 603 639 40 | 4 | Bolzen | Pin |
| 04 | 490 505 40 | 4 | Sicherungsbolzen | Lock pin |
| 05 | 598 900 40 | 1 | Bolzen | Pin |
| 06 | 007 266 98 | 3 | Sicherungsfeder | Locking spring |
| 07 | 583 570 40 | 2 | Bolzen | Pin |
| 08 | 505 909 98 | 2 | Sicherungsbolzen | Lock pin |
| Wipptraverse Hauptausleger Flying Bridle Main Boom | | | | 58-6070 Seite/Page 2/2 |