



Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	103 180 12	1	Anschlußkopf, kpl.	Head adapter assy.
01	103 181 12	1	Anschlußkopf SK	Head adapter, weldment
02	104 123 12	1	Kraftmeßdose 150t, kpl.	Load cell assy.
03	104 130 12	1	Zuglasche, kpl.	Bugle assy.
04	104 133 12	1	Achse	Axle
05	104 135 12	1	Seilschlutz	Rope deflector
06	103 900 12	3	Seilrolle 160, kpl.	Sheave assy.
07	100 114 12	2	Scheibe	Disc
08	104 137 12	2	Distanzrohr	Spacer
09	104 138 12	2	Distanzrohr	Spacer
10	104 139 12	2	Distanzrohr	Spacer
11	307 952 99	6	Schraube	Bolt
12	100 118 12	2	Sicherungsbolzen	Socket pin
13	342 081 99	2	Splint	Cotter pin
14	340 613 99	2	Scheibe	Disc
15	500 051 98	2	Bolzen	Pin
16	511 617 98	2	Sicherheitsklappstecker	Safety pin
17	534 092 99	22	Schelle	Clamp
18	332 110 99	22	Mutter	Nut
19	104 140 12	1	Endschalter s. EL-Blatt 59-6295	Limit switch see page 59-6295
-	001 853 12	1	Gleitfett	Grease
21	350 562 99	2	Schmiernippel	Grease nipple
22	104 484 12	2	Buchse	Bushing
-	130 279 12	1	Elektrik Anschlußkopf s. EL-Blatt 62-6220	Electric head adapter see page 62-6220
31	104 124 12	1	Kraftmeßdose 150t SK	Load cell, weldment
32	104 127 12	1	Buchse	Bushing
33	313 502 99	2	Ringschraube	Eyebolt
34	104 129 12	1	Kraftmeßdose KMD 150t	Load cell
35	350 562 99	1	Schmiernippel	Grease nipple
41	103 901 12	1	Seilrolle	Sheave
42	500 359 98	1	Rollenlager	Roller bearing
43	342 594 99	2	Sicherungsring	Circlip
46	104 131 12	1	Zuglasche SK	Bugle
47	104 127 12	1	Buchse	Bushing
48	350 562 99	1	Schmiernippel	Grease nipple

Anschlußkopf
Head adapter

59-6030

Seite/Page 2 / 2