



**62-6278**

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
00	130 046 12	1	Windmeßanlage, kpl.	Air speed indication arr. assy.
01	889 003 40	1	Windgeber, kpl.	Anemometer assy.
02	881 574 40	1	Halterohr	Stay tube
03	505 908 98	1	Sicherungsbolzen	Lock pin
04	319 561 99	3	Schraube	Screw
05	509 859 98	3	Mutter	Nut
06	346 508 99	3	Federring	Lock washer
11	655 175 40	1	Anemometer	Anemometer
12	047 250 40	1	Stecker	Plug
13	604 893 40	1	Stiftträger	Plug carrier
14	592 021 40	6	Stiftkontakt	Male contact
15	592 943 40	1	Buchsenkontakt	Female contact
16	047 249 40	1	Verschußdeckel	Dust cap
17	047 252 40	1	Tülle	Spout
18	510 484 98	1	Blechschrabe	Screw
20	420 052 12	3	Schalenstern	Cup anemometer
21	418 298 12	1	Kabelverschraubung	Cable union

**Windmeßeinrichtung**  
**Air Speed Indication Arrangement**

**62-6278**

Seite/Page 2 / 2