



801-2110

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	454 708 40	1	Verteilerkasten	Distribution box
01	330 871 40	1	Leergehäuse	Housing, empty
02	505 954 99	1	Hutschiene	Head band
03	346 499 99	2	Federring	Lock washer
04	320 819 99	2	Schraube	Bolt
05	356 265 40	2	Endklammer	Clamp
06	356 274 40	2	Klemme	Clip
07	356 264 40	35	Klemme	Clip
08	356 266 40	1	Abschlußplatte	Cover plate
09	323 982 40	3	Schlauchverschraubung	Union
10	324 837 40	3	Schutzschlauch	Protecting hose
11	323 983 40	3	Innentülle	Socket
12	336 717 40	3	Endtülle	Socket
13	270 250 40	2	Kabelverschraubung	Cable union
22	323 248 40	2	Temperatur-Schaltgerät	Temperature switch box

Verteilerkasten /Steuerung Oberwagen
Distribution Box /Control Superstructure

801-2110

Seite/Page 2 / 2