





90-0711



90-0711

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal	Gegenstand Description Designation Descripcion Designazione Benaemning	
00	454 128 40	1	Lenkachse	Steering axle
01	777 749 73	1	Achsgehäuse	Axle housing
02	997 363 00	2	Wellenmutter	Shaft nut
03	347 415 99	2	Gewindestift	Threaded pin
04	997 386 00	2	Nasenscheibe	Gib disc
05	957 340 00	2	Kegelrollenlagerinnenring	Tapered roller bearing cap
06	957 339 00	2	Kegelrollenlageraußenring	Tapered roller bearing cone
07	504 337 98	2	Nilosring	Nilos ring
08	361 595 99	2	Kegelrollenlager	Roller bearing
09	500 200 98	2	Dichtring	Seal ring
10	956 082 00	2	Abstandsring	Spacer
11	771 277 00	2	Radnabe	Wheel hub
12	771 289 00	2	Verschlußkappe	Cap
13	320 345 99	12	Schraube	Screw
14	997 106 00	20	Radbolzen	Wheel bolt
15	771 278 00	2	Bremsscheibe	Disc
16		32	Schraube	Screw
17	-	-	Bremse siehe EL-Blatt 90-0569	Brake see page 90-0569
21	771 292 00	2	Spurhebel	Lever
22	779 647 00	1	Lenkhebel	Steering lever
23	771 047 00	1	Deckel	Cover
24	307 615 99	16	Schraube	Screw
25	308 417 99	16	Schraube	Screw
26	771 048 00	2	O-Ring	O-ring
27	350 562 99	4	Schmiernippel	Fitting
28	771 294 00	1	Spurstange	Truck rod
31	956 139 00	2	Lagerbuchse	Bush
32	965 719 00	2	Anlaufscheibe	Stop washer
33	965 954 00	2	Achsschenkelbolzen	Steering knuckle pin
34	771 283 00	2	Lagerbuchse	Bush
35	771 051 00	2	Achsschenkelbolzen	Steering knuckle pin
36	771 284 00	2	Federbock	Support
37	319 301 99	2	Schraube	Screw
38	345 256 99	2	Zylinderstift	Parallel pin
39	771 295 00	1	Achsschenkel	Steering knuckle
40	771 295 00	1	Achsschenkel	Steering knuckle
52	777 240 73	1	Abstandsring	Spacer
53	366 926 99	2	Dichtring	Seal ring
54	504 335 98	2	Kegelrollenlager	Roller bearing
55	770 537 00	2	Antriebsflansch	Drive flange
56	760 701 00	2	Einschlagmutter	Adjusting nut
Lenkachse Steering Axle			90-0711	
			Seite/Page 3/4	

