



90-0892

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	527 058 40	1	Lenkachse	Steering axle
01	761 740 73	1	Achsgehäuse, kpl.	Axle housing, assy.
02	997 415	2	Wellenmutter	Nut
03	350 342 99	2	Schraube	Screw
04	997 103	2	Nasenscheibe	Gib disc
05	363 017 99	2	Kegelrollenlager	Roller bearing
07	534 023 99	2	Kegelrollenlager	Roller bearing
08	180 767 40	2	Dichtring	Seal ring
09	777 094 73	2	Büchse	Bushing
10	760 674	2	Radnabe	Wheel hub
11	760 675	2	Verschlusskappe	Cap
12	761 710 73	20	Radbolzen	Wheel bolt
13	761 741 73	2	Bremstrommel	Brake drum
14	350 368 99	4	Schraube	Bolt
17	761 742 73	1	Hebel	Lever
18	761 743 73	1	Hebel	Lever
19	761 744 73	1	Hebel	Lever
20	307 615 99	20	Schraube	Bolt
21	-	3	Schraube	Bolt
24	350 562 99	4	Kegelschmiernippel	Fitting
25	367 122 99	2	O-Ring	O-ring
26	761 735 73	1	Spurstange	Steering track rod
27	771 047	1	Deckel	Cover
28	956 139	2	Lagerbuchse	Bush
29	965 719	2	Anlaufscheibe	Stop washer
30	771 346	2	Lagerbuchse	Bush
31	772 366 73	2	Achsschenkelbolzen	Steering knuckle pin
32	771 284	2	Federbock	Support
33	319 311 99	2	Schraube	Bolt
34	345 629 99	2	Zylinderstift	Parallel pin
35	761 717 73	2	Achsschenkel	Steering knuckle
39	-	2	Bremse siehe EL-Blatt 90-0572	Brake see page 90-0572