



**90-1690**

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	269 250 40	1	Nehmerzylinder, kpl.	Slave cylinder, assy.
01	993 793 00	1	Kupplungsnehmergeh.	Cylinder
02	993 794 00	1	Nutring	Sealing ring
03	993 795 00	1	Kolben	Piston
--	993 796 00	1	Schutzkappe, kpl.	Protect. cap, assy.
04	993 797 00	1	Schutzkappe	Protect. cap
05	993 798 00	1	Anschlagsscheibe	Stop disc
06	993 799 00	1	Schutzkappe	Protect cap
07	987 337 00	1	Filzring	Felt ring
08	993 801 00	1	Druckbolzen	Set bolt
09	987 339 00	1	Entlüfterventil, kpl.	Aeration valve, assy.
--	648 233 00	1	Staubkappe	Dust cap
10	993 807 00	1	Federteller	Spring plate
11	993 804 00	1	Druckfeder	Pressure spring
12	993 805 00	1	Federteller	Spring plate
13	993 806 00	1	Halteblech	Retaining plate
14	500 678 98	2	Schraube	Screw
15	343 608 99	2	Fächerscheibe	Fan type lock washer
--	525 128 00	1	Reparatursatz (best. aus Bild-Nr. 02,07)	Repair kit (consists of fig-no: 02,07)

**Zylinder  
Cylinder**

**90-1690**

Seite/Page 2 / 2