


00



90-4763

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	401 603 40	1	Lenkachse, kpl.	Steering axle, assy.
01	777 326 73	1	Achsgehäuse	Axle housing
02	343 391 99	2	Wellenmutter	Shaft nut
03	343 420 99	2	Sicherungsblech	Locking plate
04	997 103 00	2	Nasenscheibe	Gib disc
05	534 023 99	2	Rollenlager	Roller bearing
06	363 017 99	2	Rollenlager	Roller bearing
07	500 200 98	2	Dichtring	Seal ring
08	760 673 00	2	Abstandsring	Spacer ring
09	760 674 00	1	Radnabe	Wheel hub
11	760 675 00	1	Verschlußkappe	Screw plug
12	997 106 00	20	Radbolzen	Wheel bolt
13	997 107 00	2	Bremstrommel	Brake drum
14	320 362 99	4	Schraube	Screw
15	997 211 00	1	Spurhebel	Lever
16	770 522 00	1	Lenkhebel	Steering lever
17	997 210 00	1	Spurhebel	Lever
18	308 417 99	24	Schraube	Screw
19	997 391 00	1	Deckel	Cover
20	307 839 99	3	Schraube	Screw
21	350 562 99	4	Schmiernippel	Fitting
23	997 209 00	1	Spurstange	Steering track rod
24	956 142 00	2	Lagerbuchse	Bush
25	956 139 00	2	Lagerbuchse	Bush
26	956 719 00	2	Anlaufscheibe	Stop washer
27	997 473 00	2	Achsschenkelbolzen	Steering knuckle pin
28	997 113 00	1	Achsschenkel	Steering knuckle
29	997 118 00	1	Achsschenkel	Steering knuckle
30	-	-	Bremse siehe EL-Blatt 90-4111	Brake see page 90-4111
31	668 289 00	2	Lenkbegrenzung	Steering block
32	308 417 99	2	Schraube	Screw
33	333 185 99	2	Mutter	Nut
34	308 003 99	12	Schraube	Screw

Lenkachse
Steering Axle

90-4763

Seite/Page 2 / 2