


00



90-4767

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	401 607 40	1	Lenkachse	Steering axle
01	777 329 73	1	Achsgehäuse, kpl.	Axle housing, assy.
02	343 391 99	2	Wellenmutter	Nut
03	343 420 99	2	Sicherungsblech	Locking plate
04	997 103 00	2	Nasenscheibe	Gib disc
05	363 017 99	2	Kegelrollenlager	Roller bearing
07	534 023 99	2	Kegelrollenlager	Roller bearing
08	180 767 40	2	Dichtring	Seal ring
09	760 673 00	2	Abstandsring	Spacer ring
10	760 674 00	2	Radnabe	Wheel hub
11	760 675 00	2	Verschlußkappe	Cap
12	997 106 00	20	Radbolzen	Wheel bolt
13	997 107 00	2	Bremstrommel	Brake drum
14	320 604 99	4	Schraube	Screw
17	770 530 00	1	Lenkspurhebel	Steering lever
18	770 531 00	1	Spurhebel	Lever
20	308 417 99	24	Schraube	Screw
22	997 202 00	1	Deckel	Cover
23	307 839 99	6	Schraube	Screw
24	350 562 99	4	Kegelschmiernippel	Fitting
26	997 209 00	1	Spurstange	Steering track rod
27	956 139 00	2	Lagerbuchse	Bush
28	965 719 00	2	Anlaufscheibe	Stop washer
30	956 142 00	2	Lagerbuchse	Bush
31	997 473 00	2	Achsschenkelbolzen	Steering knuckle pin
33	997 497 00	1	Achsschenkel	Steering knuckle
34	997 118 00	1	Achsschenkel	Steering knuckle
36	760 669 00	2	Lenkanschlag	Steering block
37	308 417 99	2	Schraube	Screw
38	333 185 99	2	Mutter	Nut
39	-	2	Bremse siehe EL-Blatt 90-4111	Brake see page 90-4111

Lenkachse
Steering Axle

90-4767

Seite/Page 2 / 2