



**90-4862**

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaeming
00	433 170 40	1	Achse, kpl.	Axle assy.
01	772 131 73	1	Achsbrücke	Axle housing
02	997 363 00	2	Wellenmutter	Shaft nut
03	347 415 99	2	Gewindestift	Threaded pin
04	997 103 00	2	Nasenscheibe	Gib disc
05	957 340 00	2	Kegelrollenlagerinnenring	Tapered roller bearing cup
06	957 339 00	2	Kegelrollenlageraußenring	Tapered roller bearing cone
07	504 337 98	2	Nilosring	Nilos ring
08	361 595 99	2	Rollenlager	Roller bearing
09	500 200 98	2	Dichtring	Seal ring
10	956 082 00	2	Abstandsring	Spacer ring
11	999 848 00	1	Radnabe	Wheel hub
14	965 729 00	20	Radbolzen	Wheel bolt
15	771 056 00	2	Bremstrommel	Brake drum
16	320 363 99	4	Schraube	Screw
18	-	2	Bremse siehe EL-Blatt 90-3951	Brake see page 90-3951
21	771 380 00	1	Spurhebel	Lever
22	771 381 00	1	Spurhebel	Lever
23	771 382 00	1	Lenkhebel	Steering lever
24	308 417 99	20	Schraube	Screw
25	997 391 00	1	Deckel	Cover
26	307 839 99	3	Schraube	Screw
27	350 562 99	4	Schmiernippel	Fitting
28	999 852 00	1	Spurstange	Track rod
31	956 139 00	2	Lagerbuchse	Bush
32	956 140 00	2	Anlaufscheibe	Stop washer
33	779 858 73	2	Achsschenkelbolzen	Steering knuckle pin
34	956 142 00	2	Lagerbuchse	Bush
35	956 143 00	2	Achsschenkelbolzen	Steering knuckle pin
41	772 132 73	1	Achsschenkel	Steering knuckle
42	771 394 00	1	Achsschenkel	Steering knuckle

**Achse  
Axle**

**90-4862**

Seite/Page 2 / 2