



90-4876

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	433 670 40	1	Lenkachse	Steering axle
01	772 374 73	1	Achsgehäuse, kpl.	Axle housing, assy.
02	343 391 99	2	Wellenmutter	Nut
03	343 420 99	2	Sicherungsblech	Locking plate
04	997 103 00	2	Nasenscheibe	Gib disc
05	363 017 99	2	Kegelrollenlager	Roller bearing
07	534 023 99	2	Kegelrollenlager	Roller bearing
08	180 767 40	2	Dichtring	Seal ring
09	760 673 00	2	Abstandsring	Spacer ring
10	760 674 00	2	Radnabe	Wheel hub
11	760 675 00	2	Verschlußkappe	Cap
12	760 676 00	20	Radbolzen	Wheel bolt
13	997 471 00	2	Bremstrommel	Brake drum
14	320 604 99	4	Schraube	Bolt
17	772 375 73	1	Hebel	Lever
18	772 376 73	1	Hebel	Lever
19	772 377 73	1	Hebel	Lever
20	308 417 99	24	Schraube	Bolt
21		3	Schraube	Bolt
24	350 562 99	4	Kegelschmiernippel	Fitting
25	367 122 99	2	O-Ring	O-ring
26	771 287 00	1	Spurstange	Steering track rod
27	771 047 00	1	Deckel	Cover
28	956 139 00	2	Lagerbuchse	Bush
29	965 719 00	2	Anlaufscheibe	Stop washer
30	771 346 00	2	Lagerbuchse	Bush
31	772 366 73	2	Achsschenkelbolzen	Steering knuckle pin
32	771 284 00	2	Federbock	Support
33	319 311 99	2	Schraube	Bolt
34	345 629 99	2	Zylinderstift	Parallel pin
35	997 118 00	2	Achsschenkel	Steering knuckle
39	-	2	Bremse siehe EL-Blatt 90-3951	Brake see page 90-3951
40	780 163 73	2	Anlaufscheibe	Stop washer

**Achse 5  
Axle 5**

**90-4876**

Seite/Page 2 / 2