



Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	295 380 40	1	Tachograph	Tachograph
02	263 130 40	1	Kombi-Instrument	Multiple indication assy.
03	770 722 00	1	Temperatur Anzeige Getriebe	Temperature indicator gear box
04	208 933 40	1	Zündstartschalter	Ignition switch
05	385 213 40	1	Zigaretten-Anzünder	Cigarette lighter
06	415 847 40	1	Bedienungsschalter - Heizung	Operating switch - heater
07	263 324 40	2	Halteklammern	Clamp
08	263 322 40	4	Spreizscheiben	Shim
09	356 254 40	21	Meldeleuchte	Signal light
10	356 256 40	9	Druckhaube, rot	Push hood, red
11	356 257 40	14	Druckhaube, gelb	Push hood, yellow
12	414 245 40	1	Druckhaube, blau	Push hood, blue
13	368 183 40	2	Druckhaube, grün	Push hood, green
14	356 156 40	27	Glühlampe	Bulb
15	356 255 40	26	Blindplatte	Blank plate
16	363 406 40	1	Tastenkippsschalter - Lichtschalter	Push-toggle switch - lighting
17	461 230 40	1	Tastenkippsschalter - Nebelschlußleuchte	Push-toggle switch - fog tail light
18	461 230 40	1	Tastenkippsschalter - Rundumleuchte	Push-toggle switch - omnidirect. light
19	363 414 40	1	Tastenkippsschalter - Motorstop	Push-toggle switch - engine-stop
20	363 408 40	1	Tastenkippsschalter - Heizung/Lüftung	Push-toggle switch - heater/fan
21	363 409 40	1	Tastenkippsschalter - Längssperre	Push-toggle switch - straight-lock
22	363 409 40	1	Tastenkippsschalter - Quersperre	Push-toggle switch - cross-lock
23	414 018 40	1	Tastenkippsschalter - Warnblinkschalter	Push-toggle switch - hazard switch
24	414 755 40	1	Tastenkippsschalter - Scheibenwischer	Push-toggle switch - wiper
25	363 426 40	1	Symbol	Symbol
26	461 751 40	1	Symbol	Symbol
27	461 750 40	1	Symbol	Symbol
28	461 749 40	1	Symbol	Symbol
29	461 786 40	1	Symbol	Symbol
30	363 417 40	1	Symbol	Symbol
31	364 140 40	1	Symbol	Symbol
32	461 787 40	1	Symbol	Symbol
33	363 410 40	9	Blende	Blank plate

**Armaturenbrett
Instrument panel**

905-2110

Seite/Page 2 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
34	318 576 40	20	Schraube	Screw
35	418 991 40	12	Symbolfolie	Symbolic foil
36	368 044 40	6	Leuchtdrucktaster	Luminous touch contact
37	356 258 40	3	Schlüsselschalter	Key switch
38	256 587 40	1	Alarmsummer	Warnung buzzer
39	440 394 40	3	Leuchtdiode, rot	Diode, red
40	440 393 40	3	Druckhaube, rot	Push hood, red
41	414 756 40	1	Symbol	Symbol
42	442 735 40	1	Blende	Blank plate
43	318 576 40	2	Schraube	Screw
-	453 292 40	1	Symbol	Symbol

**Armaturenbrett
Instrument panel**

905-2110

Seite/Page 3 / 3