



907-3600

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	-	1	Lenktriebachse I s. EL-Blatt 90-2833	Steering drive axle see page 90-2833
02	432 055 40	2	Membranzylinder	Diaphragm cylinder
03	509 562 98	4	Schraube	Bolt
04	551 226 40	2	Achsstrebe	Axle brace
05	515 867 40	2	Lenkzylinder	Steering cylinder
-	777 939 73	2	Dichtsatz zu Bild-Nr. 05	Seal kit to fig-no. 05
-	979 181 73	2	Reparatursatz zu Bild-Nr. 05	Repair kit to fig-no. 05
06	450 620 40	4	Kugelgelenkkopf	Knuckle
07	621 762 40	1	Stößelschalter (Öffner)	Tappet switch (N.O.)
19	604 259 40	2	Membran-Federspeicher- zylinder	Diaphragm-type spring actuator
20	604 025 40	4	Mutter	Nut
34	551 471 40	2	Achsstrebe	Axle brace
36	509 562 98	8	Schraube	Bolt
37	510 126 98	12	Schraube	Bolt
41	542 591 40	2	Bolzen ø 45	Pin
42	342 540 99	6	Sicherungsring	Circlip
43	542 625 40	2	Bolzen ø 40	Pin
44	339 513 99	6	Scheibe	Disc
47	542 624 40	4	Distanzring	Spacer
49	-	2	Federungszyylinder s. EL-Blatt 90-1721	Suspension cylinder see page 90-1721
50	529 086 40	2	Initiator mit Kabel	Proximity switch with cable
50	604 613 40	2	Initiator ab Bau Nr. 71 033	Proximity switch from s/no. 71 033 up
-	979 370 73	2	Winkelstecker zu Bild Nr. 50	Elbow plug to fig. no. 50

**Achseinbau 1. Achse
Axle Mounting 1. Axle**

907-3600

Seite/Page 2 / 2