



**910-3622**

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
--	304 521 12	1	Achseinbau, 4 Achse	Axle mounting, axle 4
01	672 214 40	1	Lenktriebachse s. EL-Blatt 993-0915	Steering drive axle see page 993-0915
02	387 620 40	2	Tristop-Zylinder	Tri-stop cylinder
03	604 025 40	2	Kronenmutter	Castel nut
04	125 155 99	4	Schraube	Bolt
05	672 284 40	4	Achsstrebe	Axle brace
06	504 812 98	4	Schraube	Bolt
07	547 333 40	1	Lenkstange	Steering rod
08	450 620 40	2	Kugelgelenkkopf	Knuckle
09	604 678 40	1	Lenkzylinder	Steering cylinder
10	001 887 12	1	Stößelschalter Öffner	Tappet switch N.C.
12	551 958 40	4	Stutzen	Socket
13	592 200 40	4	Prüfanschluß	Test point
14	224 301 40	4	O-Ring	O-ring
15	224 299 40	4	Druckring	Thrust collar
16	509 890 98	4	Mutter	Nut
17	592 201 40	4	Stutzen	Socket
18	551 533 40	2	Stutzen	Socket
19	592 049 40	2	Stutzen	Socket
20	192 198 40	2	Dichtring	Seal ring
31	576 027 40	4	Schlauchleitung	Hose assy.
32	547 256 40	1	Schlauchleitung	Hose assy.
33	592 486 40	1	Schlauchleitung	Hose assy.

**Achseinbau 4. Achse  
Axle Mounting 4th. Axle**

**910-3622**

Seite/Page 2 / 2