


968-2110b

Seite/Page 1 / 3



968-2110b

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	228 738 12	1	Armaturenblech	Instrument board panel LH
02	228 723 12	1	Armaturenblech	Instrument board panel RH
03	421 608 12	1	Anzeigeelement	Indicator
04	131 306 12	1	Meldeleuchtemodul	Indicator light modul
05	131 307 12	1	Meldeleuchtemodul	Indicator light modul
06	131 308 12	1	Meldeleuchtemodul	Indicator light modul
07	131 309 12	1	Meldeleuchtemodul	Indicator light modul
08	131 314 12	1	Meldeleuchtemodul	Indicator light modul
09	002 810 12	1	Tachograph (Km/h)	Tachograph (Km/h)
09	021 335 12	1	Tachograph (mph)	Tachograph (mph)
10	654 186 40	1	Zündstartschalter	Ignition switch
11	417 386 40	1	Zigarettenanzünder	Cigarette lighter
12	490 582 40	1	Einbausteckdose	Built-in socket
13	461 232 40	1	Tastenkippeschalter	Push-toggle switch
14	524 991 40	5	Tastenkippeschalter	Push-toggle switch
15	551 036 40	2	Tastenkippeschalter	Push-toggle switch
16	461 507 40	4	Tastenkippeschalter	Push-toggle switch
17	551 038 40	4	Tastenkippeschalter	Push-toggle switch
18	414 018 40	1	Tastenkippeschalter	Push-toggle switch
19	363 410 40	17	Blindplatte	Blank plate
24	228 749 12	1	Symboleinsätze	Set of symbols
25	507 049 98	14	Schraube	Screw
26	490 943 40	14	Rosette	Fitting
29	131 977 12	6	Glühlampe	Bulb
31	515 398 40	1	Symbol "Hundegang"	Symbolic "Crab walk"
32	201 315 12	1	Gebläseschalter	Blower switch
33	201 316 12	1	Drehknopf	Control knob
41	621 415 40	50	Glühlampe	Bulb
42	973 934 73	1	Schlüssel zu Bild-Nr.: 10	Key to fig-no.: 10
45	133 881 12	1	Radio mit CD	Radio with CD
50	412 166 12	1	Display Ganganzeige	Display, shift indicator
51	405 326 12	3	Bedienknopf	Operation button

**Armaturenbrett
Dash Board**

968-2110b

Seite/Page 3 / 3